

---

# Instruction Manual

UP27  
Program Controller  
Initial Setup Manual

IM 4P2F5-02E  
1995. Jan. 1st Edition

---

## CONTENTS

<b>1. WHEN THE INSTRUMENT IS DELIVERED .....</b>	<b>2</b>
1.1 Checking Instrument Specifications and Accessories .....	3
1.2 Component Names and Functions .....	4
1.3 Checking Measurement Input Range Code and Control Output Type Code .....	5
1.4 Preparing for Operation .....	6
<b>2. CHANGING INPUT/OUTPUT TYPES .....</b>	<b>7</b>
2.1 Changing Measurement Input Range Code .....	8
2.2 Changing Control Output Type Code .....	10
<b>3. DIP SWITCH TYPE SETTINGS AND MODE SELECTIONS .....</b>	<b>11</b>
3.1 Selecting Control Output Behavior During Error Conditions .....	11
3.2 Selecting Operating/Setup Parameter Setup Mode .....	12
<b>4. MOUNTING .....</b>	<b>13</b>
4.1 Mounting Location .....	13
4.2 Mounting Procedure .....	13
4.3 Outline Drawings and Panel Cutout Dimensions .....	14
<b>5. WIRING .....</b>	<b>16</b>
5.1 Wiring Procedure .....	16
5.2 Notes on Wiring .....	17
5.3 Terminal Wiring Diagrams .....	18
<b>6. COMPONENT NAMES AND FUNCTIONS .....</b>	<b>20</b>
<b>7. KEY OPERATION PRINCIPLES .....</b>	<b>22</b>
<b>8. OPERATING PARAMETERS .....</b>	<b>24</b>
8.1 Operating Parameter Setup Flow .....	24
8.2 Summary of Operating Parameters .....	26
8.3 Description of Operating Parameters .....	29
<b>9. SETUP PARAMETERS .....</b>	<b>42</b>
9.1 Setup Parameter Setup Flowchart .....	42
9.2 Setup Parameter Summary .....	44
9.3 Description of Setup Parameters .....	47
<b>10. OTHER FUNCTIONS .....</b>	<b>54</b>
10.1 Coordinated Operation .....	54
10.2 /LPS: Transmitter Loop Power Supply (Option Specification) .....	55
<b>11. STANDARD SPECIFICATIONS .....</b>	<b>56</b>

# 1. WHEN THE INSTRUMENT IS DELIVERED

Thank you for purchasing the UP27 program controller.

This instrument is provided with two user manuals: this "Initial Setup Manual" and a separate "Operation Manual". Information is divided between these manuals as follows.

## Initial Setting Manual

- ◎ When the instrument is delivered  
(instrument checkout)
- ◎ Changing input/output types
- ◎ Mounting
- ◎ Wiring Procedure
- ◎ Component names and functions
- ◎ Summary and description of parameters
- ◎ Coordinated operation (overview)
- ◎ Standard specifications

## Operation Manual

- ◎ Handling instructions
- ◎ Key operations
  - Setting the operating parameters
    - PID constants
    - Fixed set point control (local mode) parameters
    - Program patterns Etc.
  - General operation
    - Start/stop
    - Mode switching Etc.
- ◎ Maintenance, and Response to Malfunctions

## History

IM 4P2F5-02E

Jan, 1995 1st Edition New Publication

This manual covers these topics. For details, see the Table of Contents.



## 1.1 Checking Instrument Specifications and Accessories

Verify that the specifications of the instrument that you have received match the model and suffix codes of the instrument ordered.

### Model and Suffix Code Table

Model	Suffix code	Description
UP27	.....	Program controller
Option codes	/RET	Retransmission (4 to 20 mA DC)
	/RS422	RS-422A communication interface
	/LPS	Transmitter Loop Power Supply


Check that the following items are included.

- UP27 ..... 1
- Brackets (for mounting hardware) ..... 2
- Initial Setup Manual (this manual) ..... 1
- Operation Manual ..... 1
- Communication Manual ..... 1\*

\* Included with option code /RS422 only

## 1.2 Component Names and Functions

- The UP27 is made up of the components shown in the diagram.



### 1.3 Checking Measurement Input Range Code and Control Output Type


- Unless otherwise specified, the UP27 is shipped from the factory with the following measurement input range code and control output type.

	Measurement input range code	Control Output type
UP27	0 (thermocouple type K, -200 to 1200 °C) DIP switch No. 1: ON	(time proportioning PID, relay output) DIP switch No.5: ON, No.6: ON

- As shipped from the factory, the UP27 control action is set for reverse action.
- If a change is required in order to use this instrument, refer to Section 2, "Changing Input/Output Types".

## 1.4 Preparing for Operation

Follow the flow diagram shown below to prepare the UP27 for operation.



**Note 1:** The UP27 has no power switch. When power is supplied to it, the UP27 goes to immediately to an operating condition and begins to execute control operations. Therefore we recommend that you not connect its output to the device to be controlled until just before you are ready to begin actual operation.

**Note 2:** When received, this instrument's setpoint and operating parameters will be set to the default values in effect when it was shipped from the factory, as given in Section 8.2, "Operating Parameter Summary" (p. 26).


## 2. CHANGING INPUT/OUTPUT TYPES

The measurement input range code and the control output type code on the UP27 can be changed using switches inside the UP27.

To do this, first perform the following procedure to pull out the internal unit.

- ① Turn OFF power to the UP27.
- ② Pull out the internal unit.

Pressing the stopper at the bezel bottom, pull the internal chassis forward.




**Note:** After making the changes, return the internal unit to the case, and turn power ON.



## 2.1 Changing Measurement Input Range Code

DIP switch (B) and rotary switch (A) (see p. 4) are used to change the measurement input range code.


Use a small Phillips screwdriver to turn the rotary switch (A) arrow to the appropriate range code No. (Unless otherwise specified, this is set to "thermocouple type K,  $-200$  to  $1200^{\circ}\text{C}$ " when the UP27 is shipped from the factory.)



To select thermocouple input, set DIP switch No. 1 to ON


**Table 1. Thermocouple Input Range Codes**

Thermocouple type	Instrument range		DIP switch No.1	Input range code (Note 1)
K	$-200\sim 1200^{\circ}\text{C}$	$-300\sim 2300^{\circ}\text{F}$	ON	0
K	$-199.9\sim 999.9^{\circ}\text{C}$	$0\sim 2300^{\circ}\text{F}$		1
K	$-199.9\sim 500.0^{\circ}\text{C}$	$-199.9\sim 999.9^{\circ}\text{F}$		2
J	$-199.9\sim 800.0^{\circ}\text{C}$	$-300\sim 1500^{\circ}\text{F}$		3
T	$-199.9\sim 400.0^{\circ}\text{C}$	$-199.9\sim 750.0^{\circ}\text{F}$		4
T	$0.0\sim 400.0^{\circ}\text{C}$	$-300\sim 750^{\circ}\text{F}$		5
T	$-199.9\sim 200.0^{\circ}\text{C}$	$-199.9\sim 400.0^{\circ}\text{F}$		6
B	$0\sim 1800^{\circ}\text{C}$	$32\sim 3300^{\circ}\text{F}$		7
S	$0\sim 1700^{\circ}\text{C}$	$32\sim 3100^{\circ}\text{F}$		8
R	$0\sim 1700^{\circ}\text{C}$	$32\sim 3100^{\circ}\text{F}$		9
N	$0\sim 1300^{\circ}\text{C}$	$32\sim 2400^{\circ}\text{F}$		A
W	$0\sim 2300^{\circ}\text{C}$	$32\sim 4200^{\circ}\text{F}$		B
E	$-199.9\sim 800.0^{\circ}\text{C}$	$-300\sim 1500^{\circ}\text{F}$		C
L	$-199.9\sim 800.0^{\circ}\text{C}$	$-300\sim 1500^{\circ}\text{F}$		D
U	$-199.9\sim 400.0^{\circ}\text{C}$	$-300\sim 750^{\circ}\text{F}$		E
U	$0.0\sim 400.0^{\circ}\text{C}$	$-199.9\sim 750.0^{\circ}\text{F}$		F




Note 1:

Turn the rotary switch (A) arrow to the No. for the range code No. (Example shows thermocouple type J selected.)



**Table 2. RTD/DC Voltage Input Range Code**

RTD/ DCV Type	Instrument range		DIP switch No.1	Input range code (Note 2)
JPt100	-199.9~500.0°C	-199.9~999.9°F	OFF	0
	0.0~200.0°C	32.0~400.0°F		1
	0.0~100.0°C	32.0~200.0°F		2
	-100.0~100.0°C	-199.9~200.0°F		3
Pt100	-199.9~640.0°C	-300~ 1200°F		4
	-199.9~500.0°C	-199.9~999.9°F		5
	0.0~200.0°C	32.0~400.0°F		6
	0.0~100.0°C	32.0~200.0°F		7
	-100.0~100.0°C	-199.9~200.0°F		8
-10~10mV	Scaling can be performed within the following four ranges.			9
0~10mV				A
0~100mV				B
0~1V				C
0~5V				D
1~5V				E
0~10V				F



Note 2:

Turn the rotary switch (A) arrow to the No. for the range code No.  
(Example shows DC voltage, 1 to 5 V selected.)

Note: After changing the measurement input range code, return the internal unit to the case, and turn power ON.

Changing between °C and °F is done by changing the setup parameter (in the measurement input parameters) for the display units (UNI).

## 2.2 Changing Control Output Type Code

To set the control output type, turn ON or OFF DIP switch No.5 and No.6 (Unless otherwise specified, the control output type is preset to "Time-proportional PID (relay) output" on shipment.)


Control output type	Specifications	DIP switch
Time-proportional PID relay output (Note 1)	Contact rating: 250V AC, 3A (resistive load) Cycle time: 1 to 240 seconds (selectable)	
Time proportioning PID voltage pulse output	ON voltage: 12V DC (approx.) or greater OFF voltage: 0.1V DC maximum (load resistance: 600Ω minimum) Cycle time: 1 to 240 seconds (selectable)	
Continuous PID output	Output current: 4 to 20mA DC (load resistance: 600Ω maximum) Accuracy, $\pm 0.3\%$ (of full scale) Output update interval: 200ms	
ON/OFF relay output (Note 1)	Contact rating: 250V AC, 3A (resistive load) Output update interval: 200ms	

Note 1: The relay is socketed and replaceable. If necessary, replace with a DS power relay (Model DSP1, 12 V DC, AGP20139, Matsushita Electric).

### 3. DIP SWITCH TYPE SETTINGS AND MODE SELECTIONS


The DIP switch is located inside the UP27. (See p.7), and pull out the internal unit. All DIP switch positions are set to ON when the UP27 is shipped from the factory.

Note: DIP switch No.3 always must be ON. Otherwise, UP27 does not operate normally.




#### 3.1 Selecting Control Output Behavior During Error Conditions (See IM5B4B7-20E, Chapter 6.3)

By setting DIP switch No. 1 to ON or OFF, you can select whether the output during error conditions will be set to 0% (minimum) or 100% (maximum).



### 3.2 Selecting Operating/Setup Parameter Setup Mode

By setting DIP switch No. 4 to ON or OFF, you can select whether the UP27 will operate in operating parameter setup mode or setup parameter setup mode.



Note: Operating parameter setup mode is called up by pressing the **(SET/ENT)** key for at least three seconds from the Operation Display (see p.22).

## 4. MOUNTING

### 4.1 Mounting Location

Select a location that meets the following conditions to install this instrument.

- (1) Minimal mechanical vibration
- (2) Free of corrosive gases
- (3) Near normal room temperature (23 °C), with minimal temperature variation
- (4) No direct exposure to high radiant heat levels
- (5) Free of electromagnetic field effects
- (6) Not exposed to contact with water

### 4.2 Mounting Procedure

- (1) Insert the UP27 from the front of the panel.
- (2) Use the accessory brackets to mount the UP27 to the panel. Be careful not to overtighten the screws when mounting.



### CAUTION



CAUTION: WHEN MOUNTING ON OR OVER A COMBUSTIBLE SURFACE, A PLATE OF AT LEAST 1.43mm GALVANIZED OR 1.6mm UNCOATED STEEL EXTENDED AT LEAST 150mm BEYOND THE EQUIPMENT ON ALL SIDES MUST BE INSTALLED and

AVERTISSEMENT: LORSQUE L'APPAREIL EST INSTALLÉ SUR OU AU-DESSUS D'UNE SURFACE COMBUSTIBLE, ON DOIT PRÉVOIR UNE PLAQUE D'ACIER GALVANISÉ D'AU MOINS 1.43mm OU UNE PLAQUE D'ACIER SANS REVÊTEMENT DE 1.6mm SE PROLONGEANT SUR AU MOINS 150mm TOUT AUTOUR DE L'APPAREIL.

### 4.3 Outline Drawings and Panel Cutout Dimensions

Units: mm  
[approx. inch]







## 5. WIRING

### 5.1 Wiring Procedure


When wiring, refer to Section 5.3, "Terminal Wiring Diagrams," and conform to the instructions below.

- (1) For thermocouple input, use the prescribed type of compensating lead wires (thermocouple extension wire).
- (2) For RTD input, use wiring with low lead wire resistance and no difference in resistance between the three wires.
- (3) For power supply wiring, use wire or cable equivalent or superior to 600 V PVC insulated wire (JIS C3307). If required, insert a noise filter in the wiring.
- (4) Ground the UP27 so that resistance to ground does not exceed  $100\Omega$ , using wire having a cross-sectional area of at least  $2\text{ mm}^2$ .
- (5) Plan the routing of input circuit wiring so as to avoid noise pickup in the input circuit.
  - (a) Keep the input circuits separated as far as possible from the power supply and ground circuits.
  - (b) Shielded wire can be used to counter noise caused by electrostatic induction. The shield can be connected to the UP27 ground terminal if necessary (but be careful to avoid 2-point grounding — ground the shield either at the signal source or UP27, but not both).
  - (c) To counter noise from magnetic induction, you can obtain relatively good results by using twisted-pair input wiring with a short pitch between twists.
- (6) We recommend that you use insulated sleeve crimp terminals (for 3.5 mm screws) to connect the wiring to the terminals.


## 5.2 Notes on Wiring

- (1) There is no fuse or power supply switch in the UP27. If required, you should provide these separately.  
For fusing, use a time-lag fuse with a rated voltage of 250 V and a rated current of 1 A.
- (2) If the load exceeds the contact rating when using relay contact output (control output: 250 V AC, 3 A, resistive load; alarm output: 250 V AC, 1 A, resistive load), use an auxiliary relay to switch the load.
- (3) When using an inductive load such as an auxiliary relay on the relay contact output, connect an RC (for AC) or diode (for DC) surge suppresser circuit in parallel with the contacts to prevent arcing across the contacts.


### • For a DC Relay:




### • For an AC Relay:




## 5.3 Terminal Wiring Diagram



(With /RET specified)




(With /LPS specified)




External contact capacity: 12V DC, 10 mA or more

External contact selection for program pattern and operation mode				
[With /RS422 not specified]			[With /RS422 specified]	
Term. no.	DIS = 0	DIS = 4	Term. no.	DIS = 0 DIS = 1 DIS = 2 DIS = 3 DIS = 4
18	Pattern 8		18	Pattern 8 HOLD ADVANCE ADVANCE ADVANCE
19	Pattern 4		19	Pattern 4 HOLD Pattern 4
20	Pattern 2		20	Pattern 2
29	Pattern 1		29	Pattern 1
9	RESET		21	Not used (for /RS-422)
10	P. RUN		22	Not used (for /RS-422)
21	ADVANCE		9	RESET
22	HOLD KEYLOC		10	P. RUN
11	COM		11	COM


\*1 Specifying DIS (setup parameter) code (0 to 4) changes the function of terminals (18), (19), (22).




### Pattern end and time event output




### Power supply









### Alarm output




## 6. COMPONENT NAMES AND FUNCTIONS



Key	Function
<b>PT.No.</b>	<ul style="list-style-type: none"> <li>Selects a program pattern No. with the Operation Display on display.</li> </ul>
<b>RUN</b>	<ul style="list-style-type: none"> <li>Starts operation when pressed and held for about two seconds with the Operation Display on display.</li> </ul>
<b>RESET</b>	<ul style="list-style-type: none"> <li>Stops operation when pressed and held for about two seconds in program operation mode, local operation mode, or hold mode.</li> </ul>
<b>SET/ENT</b>	<ul style="list-style-type: none"> <li>Switches front panel from Operation Display to Operating Parameter Setup Display.</li> <li>Scrolls the display through the setup displays for the various parameters.</li> <li>Enters numeric values.</li> </ul>
<b>MODE</b>	<ul style="list-style-type: none"> <li>Transfers UP27 between its modes: hold, advance, auto/manual, local, auto tuning, etc.</li> </ul>
<b>DISP</b>	<ul style="list-style-type: none"> <li>Switches UP27 to Operation Display.</li> <li>Returns UP27 from Operating Parameter Setup Display to Operation Display.</li> </ul>
<div>▼</div> <div>▲</div>	<p>Used to alter numeric values displayed for target set points and parameters, and also for output when in manual operation mode.</p> <p>The ▼ (down) key decreases the displayed value; the ▲ (up) key increases it. Pressing either key once and releasing it will change the numeric value one digit at a time; pressing and holding the key will speed the rate of change.</p>

No.	Indicator or Display	Function
①	PVE 1 ○ (PV event 1 lamp)	Lights when PV event 1 occurs.
②	PVE 2 ○ (PV event 2 lamp)	Lights when PV event 2 occurs.
③	TME 1 ○ (Time event 1 lamp)	Lights when time event 1 occurs.
④	TME 2 ○ (Time event 2 lamp)	Lights when time event 2 occurs.
⑤	TME 3 ○ (Time event 3 lamp)	Lights when time event 3 occurs.
⑥	TME 4 ○ (Time event 4 lamp)	Lights when time event 4 occurs.
⑦	PRG ○ (Program operation mode indicating lamp)	Lights when program is running (OFF when in fixed setpoint control mode (local mode) or in reset state).
⑧	LOC ○ (Local mode indicating lamp)	Lights when UP27 is in fixed setpoint control mode (local mode).
⑨	RST ○ (Reset mode indicating lamp)	Lights when UP27 is in reset state. Program operation stops, and automatic control stops. Note that manual (MAN) mode operation is also disabled when in this state.
⑩	 (Measured value display)	Displays measured value (PV)
⑪	 (Setpoint & parameter display)	Displays target setpoint, output, segment No., remaining time in segment, and the various parameters of the UP27.
⑫	HLD ○ (Program hold indicating lamp)	Lights when program operation is in HOLD mode (temporary stop). Control continues while in this mode.
⑬	MAN ○ (Manual mode indicating lamp)	Lights when UP27 is in MAN (manual operation) mode [OFF when UP27 is in AUTO (automatic operation) mode].
⑭	AT ○ (Auto tuning execution indicating lamp)	Flashes while auto tuning is executing.
⑮		These indicate the nature of the currently running program segment:  indicates an ascending ramp;  indicates a soak segment; and  indicates a descending ramp.

## 7. KEY OPERATION PRINCIPLES



- ① When power is first applied, the UP27 displays the Operation Display. [This is if DIP switch No. 4 is set to ON (default when shipped from the factory is ON). For approximately 2 seconds after power is applied, before the Operation Display is presented, the model, input range, etc. are displayed on the measured value display.]
- ② There are three Operation Displays (SP display, output value display, and time display). The **(DISP)** key can be used to switch between these Operation Displays.
  - In local mode, the SP value can be changed from the SP display. (**(▼)**, **(▲)** + **(SET/ENT)**)
  - In MAN (manual) operation, the control output value can be changed from the output value display using the **(▼)** and **(▲)** keys.
  - From the time display, the remaining segment time can be changed if the UP27 is in hold mode or a soak segment.
- ③ With the Operation Display on display, pressing the **(SET/ENT)** key for at least three seconds will transfer the UP27 to the Operating Parameter Setup Display.
- ④ The operating parameter menu group can be changed using the **(▼)** and **(▲)** keys. Each time the **(SET/ENT)** key is pressed, the display switches to the next item in the sequence.
- ⑤ The individual operating parameters can be set (or displayed) using the **(▼)** and **(▲)** keys. (The period will be flashing while the number is being changed.) After changing a parameter value, press the **(SET/ENT)** key to register the change.
- ⑥ Pressing the **(DISP)** key with the Operating Parameter Setup Display on display returns the UP27 to the Operation Display. Pressing the **(DISP)** key while setting a parameter returns the display to the menu display.
- ⑦ If DIP switch No. 4 is OFF when power is turned ON (see p.12), the UP27 goes to the Setup Parameter Setup Display. (Note 1)
- ⑧ Each depression of the **(SET/ENT)** key (for less than three seconds) advances the display to the next setup parameter in the sequence.
- ⑨ Individual setup parameters can be set (or displayed) using the **(▼)** and **(▲)** keys. (The period will be flashing while the number is being changed.)


After changing a parameter value, press the **(SET/ENT)** key to register the change.

Note 1: After the setup parameters have been set, return DIP switch No. 4 to the ON position.




## 8. OPERATING PARAMETERS

### 8.1 Operating Parameter Setup Flow



\* If ON/OFF relay output is selected (see p.10), only HY is displayed; P, I, D, MR, OH, OL, RP, and RDV are not displayed.

Note: - is displayed in the setpoint and parameter display area (the left-hand display). This indicates that the : and : keys can be used to move between parameter groups (from control parameters to local setup related parameters).



## 8.2 Summary of Operating Parameters

Item	Symbol	Description	Setting Range	Default when shipped from factory	Customer-specified value	Reference page
Control parameters	SC	"SUPER" function ON/OFF	ON or OFF	OFF		P.30
	*.P (Note)	Proportional band	0.1 to 999.9%	5.0%		P.30
	*.I (Note)	Integral time	OFF, 1 to 6000 seconds	240 seconds		P.31
	*.D (Note)	Derivative time	OFF, 1 to 6000 seconds	60 seconds		P.31
	*.MR (Note)	Manual reset value	-5.0 to 105.0%	50%		P.32
	*.HY (Note)	ON/OFF control hysteresis	EU(0.0%)S to EU(100.0%)S	EU(0.5%)		P.32
	*.OH (Note)	Output high limit value	-5.0% < OL < OH < 105.0% (% of computed control output value)	100%		P.32
	*.OL (Note)	Output low limit value		0%		P.32
	1.RP 2.RP	Reference point 1, 2	EU(0%) < 1.RP < 2.RP < EU(100%)	EU(100%)		P.33
	RDU	Reference deviation	EU(0%) to EU(100%)	OFF		P.33

Note: ※ represents the PID group number (1 to 4).  
(See 8.1 Operating Parameter Setup Flow)

Item	Symbol	Description	Setting Range	Default when shipped from factory	Customer-specified value	Reference page
Local setup parameters	LSP	Fixed setpoint (SP)	EU(0%) to EU(100%)	EU(0%)		P.34
	PID	Local PID number	1 to 4	1		P.34
	E9A	Local event 9 (PVE 1) type	OFF, 1 to 20 (For codes, see p.40)	OFF		P.34
	E9B	Local event 9 (PVE 1) value	EU(-100%) to EU(100%)	EU(0%)		P.34
	E10A	Local event 10 (PVE 2) type	OFF, 1 to 10 (For codes, see p.40)	OFF		P.34
	E10B	Local event 10 (PVE 2) value	EU(-100%) to EU(100%)	EU(0%)		P.32
Program pattern setup parameters (continued)	SSP	Starting setpoint	EU(-100%) to EU(100%)	EU(0%)		P.36
	STC	Start code	0, 1, or 2 (For codes, see p.36)	0%		P.36
	WTM	Wait time	OFF 0.01 ~ 99.59 (hr. or min.) (1min to 99hr 59min) or (1sec to 99min 59sec) (Note)	OFF		P.38
	WZN	Wait zone	EU(0%) to EU(10%)	EU(0%)S		P.38
	RCY	Number of repeat cycles	0 to 999, CONT (continued)	0		P.39

(Note) Use "TMU" (P.42, P.45, P.49) for setting time unit (hr. or min).

Item	Symbol	Description	Setting Range	Default when shipped from factory	Customer-specified value	Reference page
(Continued)	RST	Repeat start segment No.	1 < RST < RED < 60	1		P.39
	RED	Repeat end segment No.		1		P.39
Program setup parameters	TSP	Target setpoint	EU(0%) to EU(100%)	EU(0%)		P.39
	TIM	Segment time	00.00 to 99.59 (hr. or min.) (sec to 99min 59sec) or (0min to 99hr 59min) —: Not used (Note1)	—		P.39
	EV	Event No.	0, 1 to 4, 9, 10 (None) (Time event) (PV event) (Note2)	0		P.40
	ON TV	Event data A	PV event: OFF, 1 to 10 Time event: .... Not used	OFF or 00.00		P.40
	OF PE	Event data B	00.00 to 99.59 (hours.minutes)	OFF or 00.00		P.40
	JC	Junction code	0 to 3, INS, DEL	0		p.41

(Note1) Use "TMU" (P.42, P.45, P.49) for setting time unit (hr. or min.).

(Note2) UP27 has 4 (four) events.

When 1 to 4 is specified, the events become Time events.

When 9 or 10 is specified, the events become PV events.


That is, you can use 4 (four) Time events, or use 2 (two) PV events and 2 (two) Time events, or use 3 (three) Time events & 1 (one) PV event also at the same time.



Item	Symbol	Description	Remark
Program pattern manipulation related	ALL.S S.NO	Display number of unused segments	See the "Operator's Manual" (IM 4P2F5-21E) for a description of the use of these items.
	Ptn.S P.NO	Display number of segments in specified program pattern	
	COPY NOA	Copy source program pattern No.	
	CL P.NO	Copy destination program pattern No.	

### 8.3 Description of Operating Parameters



Parameter	Description
Super Function ON/OFF SC	<ul style="list-style-type: none"> <li>○ Effects of "Super" function (overshoot suppresser)</li> <li>Use to: <ul style="list-style-type: none"> <li>● Limit overshoot</li> <li>● Increase ramp-up rate (Fixed SP control mode)</li> <li>● Cope with frequent load variations</li> </ul> </li> </ul>

"Super" is available during PID control.





Parameter	Description
Proportional Band 	<p>That control algorithm which generates a control output of magnitude proportional to the deviation is called proportional action (P action). In proportional action, the parameter called “proportional band” represents the amount of measured value (or deviation) variation (expressed in percent) required to cause the control output (control algorithm computation output) to change from 0% to 100%.</p> <p>Generally it is arranged that the output is 50% when the measured value equals the setpoint.</p> <p>Proportional action makes it possible to eliminate the output oscillation which is a disadvantage of ON/OFF action.</p> <div data-bbox="844 1050 1510 1344">  </div> <p>Deviation = Measured value – Setpoint</p>

\*: Represents the number, from 1 to 4, that will indicate to which group the parameter belongs.

Parameter	Description
Integral Time ※.I	<p>P action alone usually cannot bring the measured value exactly to the set point, since there must be some deviation to generate any output other than 50%. That control method which reduces the deviation automatically to zero by continuing to impose changes on the output as long as some deviation remains is called integral action (I action). In integral action, the parameter that determines the output rate-of-change corresponding to a given amount of deviation is called the "integral time". The shorter the integral time, the stronger the integral action (the greater the output rate-of-change).</p> <p>I action is normally combined with P action in actual use, as PI action. In PI action, the integral time (I) is the time from the instant when a step input is applied to the controlled system until the time when the additional output change due to I action is equal to that caused by the P action acting alone.</p>  <p>Deviation</p> <p>PI action output</p> <p>Output due to I action alone = equation <math>\frac{100}{P} + e \times \frac{t}{I}</math></p> <p>Output due to P action alone = equation <math>t \frac{100}{P} \times e</math></p> <p>Integral time</p>
Derivative Time ※.D	<p>If the controlled system has a long time constant or dead time, P or PI action alone may give slow response, or overshoot and make the controlled system unstable. In such cases, derivative action (D action), which imposes an output change proportional to the input (deviation) velocity, can be used to make the control system respond faster or operate stably.</p> <p>In actual use, D action is combined with P or PI action as PD or PID action.</p> <p>In PD action, the derivative time (D) is defined as the time from the instant when a ramp input (input with constant rate-of-change) is applied until the time when the output change due to P action alone equals the output change due to D action alone. The longer the derivative time, the stronger the derivative action.</p>  <p>Deviation</p> <p>Output</p> <p>PD action output</p> <p>Output due to P action alone</p> <p>Output due to D action alone</p> <p>Derivative time (D)</p>

\*: Represents the number, from 1 to 4, that will indicate to which group the parameter belongs.













Parameter	Description
Manual Reset Value ※.MR	<p>The manual reset parameter has no effect except when the integral time (I) has been set to "OFF".</p> <p>As indicated in the integral time description, P action cannot be relied upon to bring deviation to zero (the same holds for PD action). The residual deviation is referred to as "offset". By manually re-setting this "manual reset value", the operator can introduce and adjust a bias such as to eliminate the offset. (Integral action performs this reset action automatically.)</p>
ON/OFF Control Hysteresis ※.HY	<p>This parameter is displayed only when ON/OFF relay output is selected (using DIP switch (B); see p.4).</p> <p>The hysteresis is applied symmetrically around the ON/OFF operating point, and can be set as needed to prevent chatter in the control output.</p> 
Output High Limit Value ※.OH  Output Low Limit Value ※.OL	<p>The UP27 limits its control output operating range to the range between the OL and OH.</p> <p>These parameters let you specify minimum output and maximum output values in order to protect equipment, etc.</p> 

\*: Represents the number, from 1 to 4, that will indicate to which group the parameter belongs.

Parameter	Description
Reference Point 1, 2  1.RP  2.RP	<p>There are two reference points, each of which defines a PV (measured) value at which the PID set value is to be switched over to a different value.</p> <p>When the UP27 is shipped from the factory, the reference points are both set at EU(100%). Unless these values are changed, the No. 1 PID set value applies to the entire measurement range.</p> <p>In addition, a hysteresis band is provided for the PID set value switchover as shown in the figure. This band is fixed at EU(0.5%S).</p>
Reference Deviation  RDV	<p>The reference deviation parameter defines a deviation (DV) value which, if exceeded during programmed control, will cause a different PID set value (No. 4 PID set value) to be employed. This set value selection function has priority over the reference-point set value selection functions described above. It can therefore be applied to bring deviation quickly back within a target deviation band whenever a large excursion occurs, by increasing the control sensitivity (i.e., by narrowing the proportional band).</p> <p>If the reference DV is set to OFF, this function is disabled.</p> <p>The accompanying figure shows the ranges in which the No. 1 to No. 3 PID set value, and the No. 4 PID set value selected by the reference deviation, will apply in operation. A hysteresis like that provided for the reference points is provided for reference deviation, also.</p>

Parameter	Description
Fixed setpoint (SP) LSP	<p>This is the setpoint value used during fixed (local) setpoint control operation (local mode).</p> <p>It sets the target (SP) value for constant-value control.</p>
Local event 9, 10 type E9A E10A	<p>These parameters set event types (code range is 1 to 10). Parameter E9A sets the PV event 1 type (PVE1 terminal output), and parameter E10A sets up PV event 2 (PVE2 terminal output). When setting these parameters, see Table 8-1 for the event type code meanings.</p>
Local event 9, 10 set value E9B E10B	<p>These parameters set the measured value or deviation that triggers the event. (The event type defines whether to monitor the measured value or the deviation.)</p> <p>The diagrams in Table 8-1 show the relationships between this parameter's value and the UP27's operation.</p>

Table Alarm Type Code


Alarm type	Alarm action Open/Closed represents relay contact status. (Lit)/ (Extinguished) represents lamp status.	Alarm type code		Alarm type	Alarm action Open/Closed represents relay contact status. (Lit)/ (Extinguished) represents lamp status.	Alarm type code	
		Contact closed on alarm generation	Contact open on alarm generation			Contact closed on alarm generation	Contact open on alarm generation
Without alarm		OFF					
PV high limit		1	/	De-energize on deviation low limit alarm		/	6
PV low limit		2	/	Deviation high/low limit		/	7
Deviation high limit		3	/	Within deviation high/low limit		/	8
Deviation low limit		4	/	De-energize on PV high limit		/	9
De-energize on deviation high limit		/	5	De-energize on PV low limit		/	10

Parameter	Description
Starting setpoint <b>SSP</b>	This parameter is the control setpoint value from which the program pattern starts when a program operation is begun. It is used if the start code (STC) is set to "0" or "1". For details, see the start code (STC) action descriptions below.
Start code <b>STC</b>	This parameter selects one of three modes (numbered 0 to 2) for UP27 behavior at the start of a program operation. It can also be set to "-1" during setup, in which case the UP27 allows the user to set the WTM, WZN, RCY, RST, and RED parameters (the actual STC parameter will remain unchanged at its last previously set value).

**(1) When STC = 0 (start at Starting SP)**


Regardless of the PV value at time of start, the control setpoint pattern begins at the Starting SP (SSP) and ramps towards TSP1 along a straight line having a slope of

$$\frac{(TSP1 - SSP)}{TIM1}$$




**(2) When STC = 1 (PV-dependent start)**

① Example where Segment No. 2 is a soak segment:




Measured value (PV) at program operation start	Program operation start point
a	C
b	C
c	C
d	D
e	E

② Example where Segment No. 3 is a soak segment:




Measured value (PV) at program operation start	Program operation start point
a	A
b	B
c	C
d	D
e	E

## ③ Example with no soak segment:




Measured value (PV) at program operation start	Program operation start point
a	A
b	B
c	C
d	D
e	E

## ④ Example with ascending ramp only:



Measured value (PV) at program operation start	Program operation start point
a	Program operation will not be started
b	C
c	C
d	D
e	E

(3) When  $STC = 2$ 

Regardless of the measured value (PV) at program operation start, the program pattern begins with a setpoint equal to the PV and moves linearly toward the target setpoint (TSP) of Segment No. 1.


The slope is determined by the Segment No. 1 segment time parameter value.

Parameter	Description
Wait time WTM	This parameter acts together with a wait zone (see item below), setting the maximum wait time (WTM) which can elapse; after the wait time has elapsed, the program will proceed to the next segment even if the measured value has not reached the wait zone. This parameter affects operation only when junction code JC = 1 (see p41) is specified for the segment.
Wait zone WZN	This parameter defines a zone which the measured value (PV) must reach at the end of a program segment before the program will be allowed to advance to the next segment. This parameter affects operation only when junction code JC = 1 (see p.41) is specified for the segment.

There is no guarantee that the deviation will be zero at the end of a segment, and in some cases, problems will arise if the UP27 proceeds to the next segment while a large deviation is still present. In such cases, the user can specify a junction code that will delay the advance to the next segment until the deviation has decreased to within a tolerance range (called a "wait zone"), even though the segment time has already been exceeded. The user can also set a "wait time" such as to limit the maximum wait so that the program will eventually advance if the deviation does not reach the wait zone even after a considerable wait.

### [Example 1]


Here the measured value reaches the wait zone one minute after the wait action begins, and the program then moves to the following segment. This example shows the case where the PV is slow to rise to the SP, but the action would be the same if it had overshoot the SP.



### [Example 2]

Here, since the measured value has not reached the wait zone even after the wait time (WT) has elapsed (following the beginning of the wait), the UP27 advances to the next segment.


The delay in advance would be the same for  $PV > SP + WZ$ .










Parameter	Description
Number of repeat cycles <b>RCY</b>	Specifies the number of times that the program is repeated for the segment specified by the repeat start (RST) and repeat end (RED) parameters.
Repeat start segment No. <b>RST</b>	Specifies the repeat start segment No. for a repeat operation.
Repeat end segment No. <b>RED</b>	Specifies the repeat operation end segment No.


Depending on the process, a single phase may repeat the same program pattern a number of times. In such cases, the repeat can be performed from a given segment (repeat start) to a given segment (repeat end) for a given number of times (number of repeat cycles). [Note: If the number of repeat cycles is "1", the pattern is run twice (including the original cycle).

To stop the program while it is running, select RESET (this also stops control computation).


Parameter	Description
Target setpoint <b>TSP</b>	<p>The target setpoint (TSP) is the control setpoint value that is to be reached at the end of the segment. The segment time (TIM) is the length of the segment in terms of time.</p> 
Segment time <b>TIM</b>	



Parameter	Time event value	PV event value
Event No. EV 	Time event output No.1: Terminal TME1 (③) No.2: Terminal TME2 (③) No.3: Terminal TME3 (③) No.4: Terminal TME4 (③)	PV event output No. 9: Terminal PVE1 (③) No.10: Terminal PVE2 (③)
Event data A ON  TV 		PV event type OFF: Without alarm 1: PV high limit 2: PV low limit 3: Deviation high limit 4: Deviation low limit 5: Deenergized on deviation high limit 6: Deenergized on deviation low limit 7: Deviation high-low limit 8: Within high-low limit deviation 9: Deenergized on PV high limit 10: Deenergized on PV low limit
Event data B OF  PE 		PV event value IF, TY = 1, 2, 9 and 10 Measured value IF, TY = 3, 4, 5, 6, 7, and 8 Deviation value

 : Indicates event No. 1 to 4

(Nos. of Events are 1 to 4.)


- Up to 4 events (Time and PV event) can be set at same time.
- Set 1 to 4. when you use Time event (care the terminal No. of output signal). EV  1 to 4
- Set 9 or 10. when you use PV event (care the terminal No. of output signal).
- The event is activated at the start of the segment for which they are set. For example for a timer event, the timer begins counting. For a PV event, the UP27 begins making comparisons to detect the PV (measured value) or the deviation value.
- The time event parameter values can continue to have an effect even after the end of the segment, until the off (turn-off) time has passed.
- The PV event parameter value will remain in effect after the end of the segment until the operator sets EVA = 0.
- The event parameters can be re-set any number of times for the same event number. This will reactivate the event along with changing the parameters to their new values.

Parameter	Description												
Junction code  JC	<p data-bbox="516 239 1396 365">This parameter specifies how the UP27 is to behave when it finishes executing this segment and is about to move on to the next.</p> <table border="1" data-bbox="535 415 1380 1806"> <tr> <td data-bbox="535 415 695 703">JC = 0</td><td data-bbox="695 415 1380 703">           After executing this segment, the UP27 continues and executes the following segment.            If this value is set for the last segment, the UP27 will go to reset status when program execution ends.         </td></tr> <tr> <td data-bbox="535 703 695 982">JC = 1</td><td data-bbox="695 703 1380 982">           After executing this segment, the UP27 executes a wait operation before continuing to the next segment.            If this value is set for the last segment, the UP27 will go to wait status and then go to reset status when program execution ends.         </td></tr> <tr> <td data-bbox="535 982 695 1304">JC = 2</td><td data-bbox="695 982 1380 1304">           After executing this segment, the UP27 goes to HOLD mode. The HLD lamp turns ON. HOLD mode continues until it is released by a key operation or external contact.            In case that "JC = 2" is set for the last segment, UP27 goes to reset status when HOLD mode is released.         </td></tr> <tr> <td data-bbox="535 1304 695 1560">JC = 3</td><td data-bbox="695 1304 1380 1560">           After executing this segment, the UP27 goes to the LOCAL and RUN statuses. Note that if SP tracking is ON, the local SP will be set to the SP in effect at program end.         </td></tr> <tr> <td data-bbox="535 1560 695 1690">JC = INS</td><td data-bbox="695 1560 1380 1690">Set to insert a particular program segment.</td></tr> <tr> <td data-bbox="535 1690 695 1806">JC = DEL</td><td data-bbox="695 1690 1380 1806">Set to delete a particular program segment.</td></tr> </table> <p data-bbox="535 1829 1377 1871">* "JC = 3" has no effect except if set for the last segment.</p>	JC = 0	After executing this segment, the UP27 continues and executes the following segment. If this value is set for the last segment, the UP27 will go to reset status when program execution ends.	JC = 1	After executing this segment, the UP27 executes a wait operation before continuing to the next segment. If this value is set for the last segment, the UP27 will go to wait status and then go to reset status when program execution ends.	JC = 2	After executing this segment, the UP27 goes to HOLD mode. The HLD lamp turns ON. HOLD mode continues until it is released by a key operation or external contact. In case that "JC = 2" is set for the last segment, UP27 goes to reset status when HOLD mode is released.	JC = 3	After executing this segment, the UP27 goes to the LOCAL and RUN statuses. Note that if SP tracking is ON, the local SP will be set to the SP in effect at program end.	JC = INS	Set to insert a particular program segment.	JC = DEL	Set to delete a particular program segment.
JC = 0	After executing this segment, the UP27 continues and executes the following segment. If this value is set for the last segment, the UP27 will go to reset status when program execution ends.												
JC = 1	After executing this segment, the UP27 executes a wait operation before continuing to the next segment. If this value is set for the last segment, the UP27 will go to wait status and then go to reset status when program execution ends.												
JC = 2	After executing this segment, the UP27 goes to HOLD mode. The HLD lamp turns ON. HOLD mode continues until it is released by a key operation or external contact. In case that "JC = 2" is set for the last segment, UP27 goes to reset status when HOLD mode is released.												
JC = 3	After executing this segment, the UP27 goes to the LOCAL and RUN statuses. Note that if SP tracking is ON, the local SP will be set to the SP in effect at program end.												
JC = INS	Set to insert a particular program segment.												
JC = DEL	Set to delete a particular program segment.												

Note: See "Appendix," in the "Operator's Manual" (IM 4P2F5-20E).


## 9. SETUP PARAMETERS

### 9.1 Setup Parameter Setup Flowchart






Note: - is displayed in the set point and parameter display (left).

This indicates that the : and : keys can be used to move between parameter groups (from key lock parameters to measurement input parameters).



## 9.2 Setup Parameter Summary

Item	Symbol	Description	Parameter range	Default when shipped from factory	User-set value	Reference page
Key lock parameters	DAT	 key lock	OFF or ON	OFF (no lock)		P.47
	RUN	 key lock	OFF or ON	OFF (no lock)		P.47
	MOD	 key lock	OFF or ON	OFF (no lock)		P.47
	PAR	Operating parameter setup mode key lock	OFF or ON	OFF (no lock)		P.47
	PID	PID setting key lock	OFF or ON	OFF (no lock)		P.47
Measured input parameters	PD	Linear range decimal point position	0, 1, 2, or 3	Corresponds to input type when shipped from factory		P.48
	RH	Measurement range maximum value	$EU(0\%) < RL < RH < EU(100\%)$	EU (100%) [With linear input, -1999]		P.48
	RL	Measurement range minimum value	With linear input $-1999 < RL \leq RH < 9999$	EU (100%) [With linear input, -1999]		P.48
	UNI	Display units	°C or °F	°C		P.48
	BS	Measured input bias	$EU(-100.0\%)S$ to $EU(100.0\%)S$	EU (0.0%)S		P.48
	FL	Measured input filter	OFF, 1 to 120 seconds	OFF (no filter)		P.48
	RJC	RJC ON/OFF	OFF or ON	ON		P.49

Item	Symbol	Description	Parameter range	Default when shipped from factory	User-set value	Reference page																	
Set point (SP) parameter	SPT	SP tracking selection	OFF or ON	OFF (no tracking)		P.49																	
	THU	Program time setting units	“0”(OOH△△M) or “1”(OOM△△S)	0 (OOH△△M)		P.49																	
Control output parameters	DR	Direct/reverse action selection	“0” or “1” (reverse action) (direct action)	0 (reverse action)		P.50																	
	OPR	Output rate-of-change limit	0.0% to 100.0%/S (of output value) per second	0.0%/second (OFF)		P.50																	
	PST	Preset output value	-5.0% to 105.0% (of output value)	0.0%		P.51																	
	RST	Restart code	0, 1, or 2 (For meaning of codes, see p.51)	0 (continuation start)		P.51																	
	CT	Cycle time	1 to 240 seconds	30 seconds		P.51																	
	DIS	DI selection	0, 1, 2, 3 or 4 <table border="1"><thead><tr><th>DIS</th><th>(18)</th><th>(19)</th></tr></thead><tbody><tr><td>0</td><td>Pattern select 8</td><td>Pattern select 4</td></tr><tr><td>1</td><td>Hold</td><td>Pattern select 4</td></tr><tr><td>2</td><td>Advance</td><td>Pattern select 4</td></tr><tr><td>3</td><td>Advance</td><td>Hold</td></tr><tr><td>4</td><td>Advance</td><td>Pattern select 4</td></tr></tbody></table>	DIS	(18)	(19)	0	Pattern select 8	Pattern select 4	1	Hold	Pattern select 4	2	Advance	Pattern select 4	3	Advance	Hold	4	Advance	Pattern select 4	0 Pattern select 8 (18) / pattern select 4 (19)	
DIS	(18)	(19)																					
0	Pattern select 8	Pattern select 4																					
1	Hold	Pattern select 4																					
2	Advance	Pattern select 4																					
3	Advance	Hold																					
4	Advance	Pattern select 4																					








Item	Symbol	Description	Parameter range	Default when shipped from factory	User-set value	Reference page
Retransmission output/event parameters	RET	Retransmission output selection	0, 1, 2, 3, or 4 (For meaning of codes, see p.53)	0		P.53
	RTH	Retransmission range maximum value	EU(0.0%) < RTL < RTH < EU(100.0%)	Same as RH (measurement range maximum value) [EU(100.0%)]		P.53
	RTL	Retransmission range minimum value		Same as RL (measurement range minimum value) [EU(0.0%)]		P.53
	HY1	PV event 1 hysteresis	EU(0.0%)S to EU(100.0%)S	EU(0.5%)S		P.53
	HY2	PV event 2 hysteresis	EU(0.0%)S to EU(100.0%)S	EU(0.5%)S		P.53
Communication parameters	BPS	Baud rate	9600, 4800, 2400, 1200, 600, 300, or 150 bps	9600 BPS		See "Communications Manual"
	PAR	Parity	NONE, EVEN, or ODD	NONE (no parity)		
	STP	Stop bit	"1" or "2" (1 bit) (2 bits)	1 (1 bit)		
	DLN	Transmission data length	"7" or "8" (7 bits) (8 bits)	8 (8 bits)		
	ADR	Communications address	1 to 98 or 99 ("99" is for coordinated operation) (Up to 16 units can be connected)	1		

## 9.3 Description of Setup Parameters

### 9.3.1 Description of Key Lock Parameters

Each of these parameters selects either key lock (ON) or no key lock (OFF) for certain key functions. Key lock is used to prevent inadvertent actuation of these functions.

The Operation Display can be changed even if key lock is in effect.

Parameter	Description (description with lock ON)
DAT	Locks  and  keys. Disables all key operations that set or change any parameter. (Key operations can be used only to cancel this key lock status.)
RUN	Locks  ,  , and  keys. Disables the keys that select program patterns, and run and stop programs.
MOD	Locks  key. Disables the key used to select the hold (HLD), advance (ADV), auto (AUT) / manual (MAN), local (LOC), and auto-tuning (AT) modes.
PAR	Prevents the UP27 from going to operating parameter setup mode even if the  key is pressed for three seconds.
PID	Disables the setting or changing (and display) of the control related parameters (PID parameters, manual reset value, ON/OFF control hysteresis, output maximum/minimum limit, reference points, reference deviation).



### 9.3.2 Description of Measurement Input Parameters

Parameter	Description
Decimal point position PD	<p>This can be used to set the decimal point position in the input range for a voltage input such as 1 to 5 VDC.</p> <p>0 : -1999 to 9999 (no decimal point)            1 : -199.9 to 999.9 (one digit below decimal point)            2 : -19.99 to 99.99 (two digits below decimal point)            3 : -1.999 to 9.999 (three digits below decimal point)</p>
Measurement range maximum value RH	<p>These parameters are used to set the desired measurement range within the range determined by the instrument range code, by setting the measurement maximum and minimum range-values.</p> <p>Instrument range: -200 : EU(0%) °C to 1200 : EU(100%)</p> <p>Measurement range: Minimum value = -100 to Maximum value = 900</p> <p>Instrument accuracy does not change when a new measurement range is set.</p>
Measurement range minimum value RL	
Display unit UNI	<p>This can be used to set the unit (and input range) for temperature input (thermocouple or RTD) to °C or °F. This cannot be specified for voltage input. (Use accessory unit label stickers.)</p>
Measured input bias BS	<p>This functions adds a bias value to the measured input value; the result is used on the UP27 display and in control.</p> $\boxed{\text{Measured value internal to instrument}} = \boxed{\text{Measured input value}} + \boxed{\text{bias value}}$ <p>[EU(-100.0%)S ~ EU(100.0%)S]</p>
Measured input filter FL	<p>This is used when there is a great deal of fluctuation in the displayed value due to noise in the input. The filter is a first-order lag type; this parameter sets the time constant. The larger the time constant, the greater the filtering action.</p> <p>Input → Example with 2 second filter → Example with 10 second filter</p>


Parameter	Description
Reference junction temperature compensation  RJC	An electromotive force of thermocouple is generated by a temperature difference between the measurement junction and reference junction.  Consequently, any temperature variation at the reference junction will cause an error. In order to measure temperatures accurately at the measurement junction, the reference junction must be set at a fixed temperature.

### 9.3.3 Description of Setpoint Parameters

Parameter	Description
SP tracking selection  SPT	<p>SP tracking prevents bumps to the output due to abrupt changes in deviation on mode transfers from PRG to LOCAL, by forcing the LOCAL (local = internal) setpoint to track the remote setpoint.</p> <p>This parameter can be used to select OFF or ON in the SP tracking function.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> OFF : No tracking      ON : Tracking </div> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>● With SP tracking function ON</p> </div> <div style="text-align: center;"> <p>● With SP tracking function OFF</p> </div> </div>
Program time setting units  TMU	<p>Selects the time units as follows:</p> <p>0: Hours.Minutes 1: Minutes.Seconds</p>

### 9.3.4 Description of Control Output Parameters

Parameter	Description																														
Direct/Reverse action selection  DR	Direct action and reverse action define whether the output increases or decreases in response to a positive change in deviation (PV – SP); the relationship between these is as shown in the table below. <table><tr><td></td><td colspan="2">When measured &gt; setpoint</td><td colspan="2">When measured value &lt; setpoint</td></tr><tr><td>Action</td><td>Reverse action</td><td>Direct action</td><td>Reverse action</td><td>Direct action</td></tr><tr><td>ON-OFF</td><td>OFF</td><td>ON</td><td>ON</td><td>OFF</td></tr><tr><td>mA output</td><td>Current reduction</td><td>Current increase</td><td>current increase</td><td>Current reduction</td></tr><tr><td>ON OFF time proportional</td><td>ON time reduced</td><td>ON time increased</td><td>ON time increased</td><td>ON time reduced</td></tr><tr><td>Position-proportional</td><td>In direction to close L-C</td><td>In direction to close H-C</td><td>In direction to close H-C</td><td>In direction to close L-C</td></tr></table> <div><div>Direction of output change</div><div><div>24) Reverse action</div><div>31) Direct action</div></div></div>		When measured > setpoint		When measured value < setpoint		Action	Reverse action	Direct action	Reverse action	Direct action	ON-OFF	OFF	ON	ON	OFF	mA output	Current reduction	Current increase	current increase	Current reduction	ON OFF time proportional	ON time reduced	ON time increased	ON time increased	ON time reduced	Position-proportional	In direction to close L-C	In direction to close H-C	In direction to close H-C	In direction to close L-C
	When measured > setpoint		When measured value < setpoint																												
Action	Reverse action	Direct action	Reverse action	Direct action																											
ON-OFF	OFF	ON	ON	OFF																											
mA output	Current reduction	Current increase	current increase	Current reduction																											
ON OFF time proportional	ON time reduced	ON time increased	ON time increased	ON time reduced																											
Position-proportional	In direction to close L-C	In direction to close H-C	In direction to close H-C	In direction to close L-C																											
Output rate of change limit  OPR	<p>To prevent sudden disturbance to equipment and operation, an output rate of change limit can be set to limit the rate at which the output can vary. (Note: Setting the output rate of change limit may negate the effect of derivative action.)</p> <div><div>Example</div><div>Limited rate of change = 2.0 (%/second)</div><div>Set to 2.0 (%/second) for limited rate of change so that change of output from 0% to 100% requires 50 seconds.</div></div>																														

Parameter	Description														
<div>Preset output value</div> <div>PST</div>	<p>When the operating mode goes from RUN to STOP, the output value goes neither to the automatic output value nor the manual output value, but rather to a third value: this preset output value.</p> <p>When this occurs, the output maximum limit/output minimum limit, and output velocity limit are ignored.</p> <p>The transition from STOP to RUN is balanceless and bumpless.</p> <table><tr><td rowspan="3">Mode</td><td colspan="2">RUN (operation)</td><td>STOP</td></tr><tr><td colspan="2">Mode in which control program is running</td><td>Mode in which control program is stopped</td></tr><tr><td>AUTO (automatic)</td><td>MAN (manual)</td><td>—</td></tr><tr><td>Output</td><td>Output value based on control computation result</td><td>Output value based on manual key operations</td><td>Preset output value</td></tr></table>	Mode	RUN (operation)		STOP	Mode in which control program is running		Mode in which control program is stopped	AUTO (automatic)	MAN (manual)	—	Output	Output value based on control computation result	Output value based on manual key operations	Preset output value
Mode	RUN (operation)		STOP												
	Mode in which control program is running		Mode in which control program is stopped												
	AUTO (automatic)	MAN (manual)	—												
Output	Output value based on control computation result	Output value based on manual key operations	Preset output value												
<div>Restart code</div> <div>RST</div>	<p>This can be used to specify the status for operation restart when power is recovered (after a power failure, etc.)</p> <p>0 : Operation continues as before power failure when power is recovered.</p> <p>1 : When power is recovered, the UP27 goes to MAN (manual) status. The output is the value specified by the preset output value (see above).</p> <p>2 : When power is recovered, the UP 27 goes to stopped (reset) mode. The output is the value specified by the preset output value (see above).</p>														
<div>Cycle time</div> <div>CT</div>	<p>This determines the pulse output widths when the PID computation is output as an ON/OFF signal when using time proportioning PID output (relay or voltage pulse output). The output in percent corresponds to the ratio of the Ton time to the total cycle time.</p> 														

Parameter	Description																																																																																																																															
DIselection DIS	<p>This parameter assigns the functions of input terminals ⑱ and ⑲ as follows.</p> <p>External contact capacity: 12V DC, 10 mA or more</p> <table><tr><th colspan="10">External contact selection for program pattern and operation mode</th></tr><tr><th colspan="3">[With /RS422 not specified]</th><th colspan="7">[With /RS422 specified]</th></tr><tr><th>Terminal</th><th>DIS = 0</th><th>DIS = 4</th><th>Terminal</th><th>DIS = 0</th><th>DIS = 1</th><th>DIS = 2</th><th>DIS = 3</th><th>DIS = 4</th><th>*</th></tr><tr><td>⑱</td><td colspan="2">Pattern 8</td><td>⑱</td><td>Pattern 8</td><td>HOLD</td><td>ADVANCE</td><td>ADVANCE</td><td>ADVANCE</td><td></td></tr><tr><td>⑲</td><td colspan="2">Pattern 4</td><td>⑲</td><td colspan="3">Pattern 4</td><td>HOLD</td><td>Pattern 4</td><td></td></tr><tr><td>⑳</td><td colspan="2">Pattern 2</td><td>㉑</td><td colspan="6">Pattern 2</td><td></td></tr><tr><td>㉒</td><td colspan="2">Pattern 1</td><td>㉒</td><td colspan="6">Pattern 1</td><td></td></tr><tr><td>9</td><td colspan="2">RESET</td><td>㉓</td><td colspan="6">Not used (for /RS-422)</td><td></td></tr><tr><td>10</td><td colspan="2">P. RUN</td><td>㉔</td><td colspan="6">Not used (for /RS-422)</td><td></td></tr><tr><td>㉕</td><td colspan="2">ADVANCE</td><td>9</td><td colspan="6">RESET</td><td></td></tr><tr><td>㉖</td><td>HOLD</td><td>KEYLOC</td><td>10</td><td colspan="6">P. RUN</td><td></td></tr><tr><td>11</td><td colspan="2">COM</td><td>11</td><td colspan="6">COM</td><td></td></tr></table> <p>※ Specifying DIS (setup parameter) code (0 to 4) changes the function of terminals (&lt;18&gt;, &lt;19&gt;).</p>	External contact selection for program pattern and operation mode										[With /RS422 not specified]			[With /RS422 specified]							Terminal	DIS = 0	DIS = 4	Terminal	DIS = 0	DIS = 1	DIS = 2	DIS = 3	DIS = 4	*	⑱	Pattern 8		⑱	Pattern 8	HOLD	ADVANCE	ADVANCE	ADVANCE		⑲	Pattern 4		⑲	Pattern 4			HOLD	Pattern 4		⑳	Pattern 2		㉑	Pattern 2							㉒	Pattern 1		㉒	Pattern 1							9	RESET		㉓	Not used (for /RS-422)							10	P. RUN		㉔	Not used (for /RS-422)							㉕	ADVANCE		9	RESET							㉖	HOLD	KEYLOC	10	P. RUN							11	COM		11	COM						
External contact selection for program pattern and operation mode																																																																																																																																
[With /RS422 not specified]			[With /RS422 specified]																																																																																																																													
Terminal	DIS = 0	DIS = 4	Terminal	DIS = 0	DIS = 1	DIS = 2	DIS = 3	DIS = 4	*																																																																																																																							
⑱	Pattern 8		⑱	Pattern 8	HOLD	ADVANCE	ADVANCE	ADVANCE																																																																																																																								
⑲	Pattern 4		⑲	Pattern 4			HOLD	Pattern 4																																																																																																																								
⑳	Pattern 2		㉑	Pattern 2																																																																																																																												
㉒	Pattern 1		㉒	Pattern 1																																																																																																																												
9	RESET		㉓	Not used (for /RS-422)																																																																																																																												
10	P. RUN		㉔	Not used (for /RS-422)																																																																																																																												
㉕	ADVANCE		9	RESET																																																																																																																												
㉖	HOLD	KEYLOC	10	P. RUN																																																																																																																												
11	COM		11	COM																																																																																																																												

### 9.3.5 Retransmission Output and Alarm Type Parameters

Parameter	Description
Retransmission output selection <b>RET</b>	<p>Displayed only if the /RET option has been specified. Selects one of the following five types of output for the retransmission output (4 to 20 mA DC).</p> <p>0 : Measured value (scaled according to measurement range, from range low (RL) to range high (RH) value).</p> <p>1 : Setpoint value (scaled according to measurement range, from range low (RL) to range high (RH) value).</p> <p>2 : Output value</p> <p>3 : Measured value (scaled according to retransmission range, from range low (RTL) to range high (RTH) value.)</p> <p>4 : Setpoint value (scaled according to retransmission range, from range low (RTL) to range high (RTH) value).</p>
Retransmission range maximum value <b>RTH</b>	<p>When the retransmission output selection parameter is set to "3" or "4", the value output through the retransmission output is scaled using the retransmission range minimum and maximum values RTL and RTH. The accuracy conforms to that of the relationship between instrument range and measurement range (see page 48).</p>
Retransmission range minimum value <b>RTL</b>	<p>The diagram illustrates the scaling of the retransmission output. It shows two parallel horizontal axes. The top axis represents the 'Measurement range' in degrees Celsius (°C), with major tick marks at 0, 100, 900, and 1000. The bottom axis represents the 'Retransmission range' in milliamperes direct current (mA), with major tick marks at 4mA and 20mA. Vertical dashed lines connect the measurement range to the retransmission range. Specifically, a dashed line from 0°C on the top axis points down to 4mA on the bottom axis. Another dashed line from 1000°C on the top axis points down to 20mA on the bottom axis. Two intermediate points are highlighted: a dashed line from 100°C on the top axis points down to a label 'RTL = 100°C' on the bottom axis, and another dashed line from 900°C on the top axis points down to a label 'RTL = 900°C' on the bottom axis.</p>
PV event 1 hysteresis <b>HV1</b>	<p>If PV event ON/OFF switching is too frequent, a hysteresis band can be set around the events to prevent this. These bands can be set independently for PV events 1 and 2. See page 35 for a description of the event types and hysteresis action.</p>
PV event 2 hysteresis <b>HV2</b>	


## 10. OTHER FUNCTIONS

### 10.1 Coordinated Operation

Coordinated operation works when /RS422 is specified.  
(UT38 has no coordinated operation function.)

#### Feature of Coordinated operation

- With a UP27 as the master station, UT37s (up to 16 units) can be connected using the communications bus for program operation.



(Note: UT38 has no coordinated operation function)

- Through coordinated operation, the following information can be downloaded by the UP27:
  - ① Select UT37's PID parameters on a zone basis.
  - ② Select UT37 operation mode.
  - ③ Transmit setpoints to UT37 without error.
  - ④ Transfer information required to optimize SUPER operation.
- In the details, see Instruction Manual (Communication Manual) IM5B4B7-51E.


## 10.2 /LPS: Transmitter Loop Power Supply (Option Specification)

### ● Example of Connection with FP100

Power supply voltage: 21.6 ~ 28.0V(30mA MAX)

Terminal No.: ②⑦(+), ②⑧(-)

Example of ZT1000 (2-wire temperature Transmitter Connection)



Note: /LPS is not available if digital communication is simultaneously performed, overlaying the signal line.



# 11. STANDARD SPECIFICATIONS

Input: Universal Method (Input Type Selectable)	
Input sampling period:	200 ms
Input accuracy:	$\pm 0.1\%$ of F.S. $\pm 1$ digit (Input Accuracy is different according to input type/range.)
Input resistance:	Refer to General Specifications GS 4P2F5-02E Thermocouple input ..... $1\text{M}\Omega$ or more Voltage input ..... Approx. $1\text{M}\Omega$
Permissible signal source resistance:	Thermocouple ..... $250\Omega$ or less Voltage ..... $2\text{k}\Omega$ or less
Permissible wiring resistance:	RTD input ..... $10\Omega$ or less/wire
Permissible input voltage:	Thermocouple, DC voltage input ..... within $\pm 10\text{V}$
Noise rejection ratio:	Normal mode ..... 40 dB (50/60Hz) or more Common mode ..... 120 dB (50/60 Hz) or more
Filter:	OFF, 1 to 120 sec (first order lag. OFF: no filter.)
Measured input bias:	$-100.0$ to $100.0\%$ of measuring span
Thermocouple standards:	IEC/DIN (U and L)/JIS
RTD standards:	IEC/DIN/JIS '89 JPT100, PT100
<b>Display function</b>	
Display contents:	Process variable (PV), setpoint/parameter, status lamps (12)
Process variable display:	4-digit, 7-segment LEDs (red)
Setpoint or parameter display:	3-digit 5 $\times$ 7 Dot matrix LEDs + 4-digit, 7-segment LEDs (red)
Deviation monitor:	Green LED lights when deviation is within $\pm 1.0\%$ of F.S. If deviation exceeds this range, Orange LED lights.
Setting Specifications	
<b>Setting range</b>	
Measured input:	Within measuring range
Proportional band (P):	0.1 to 999.9%
Integral time (I):	OFF, 1 to 6000 sec (OFF: Integral action is OFF)
Derivative time (D):	OFF, 1 to 6000 sec (OFF: Derivative action is OFF)
Number of program patterns/segments:	15 patterns/192 segments (MAX. 60 segments per pattern)
Segment time:	0 to 99 hr. 59 min or 99 min 59 sec
Wait zone:	0 to 10%
Wait time:	OFF, 1 min to 99 hr. 59 min or 1 sec to 99 min 59 sec
<b>Setpoint Resolution for Process Input</b>	
Thermocouple input	$1^\circ\text{C}$ or $0.1^\circ\text{C}$ ( $1^\circ\text{F}$ or $0.1^\circ\text{F}$ )
RTD input	$0.1^\circ\text{C}$ ( $0.1^\circ\text{F}$ )

### Output: Universal Method (Output Type Selectable)

Output type:	Time proportional PID (relay output) Time proportional PID (voltage pulse output for driving external SSR) Continuous output PID (4 to 20mA DC output) ON/OFF (relay output)
Relay output contact rating:	250V AC, 3A (resistive load)
Voltage pulse output:	ON voltage ..... Approx. 12V DC or more (load resistance: 600Ω or more) OFF voltage ..... 0.1V DC or less
4 to 20mA DC output:	Load resistance of 600Ω or less, accuracy of $\pm 0.3\%$ of F.S., output updating period of 200 ms
Cycle time:	1 to 240 sec (relay and voltage pulse output)
Output high and low limits:	-5 to 105%
Output action selection	Direct reverse action selectable
AUTO/MAN selection:	Balanceless, bumpless selection
Output velocity limit:	0.0 to 100.0%/sec (0.0%/sec means OFF.)
Other functions:	Auto-tuning, key lock, input burn-out, and <b>SUPER</b> . Measured input and control output circuits are isolated from each other.
Isolation:	Measured input and control output circuits are isolated from each other.

### PV Event Alarm Function

Setting content:	Process variable high and low limits, deviation high and low limits, etc. (selectable for each point from among 10 types.)
Alarm value:	0 to 100% of the set range
Number of settings:	2
Output:	Relay output contact capacity: 250V AC 1A (resistive load)
Display:	LED lamp display on the front panel
<b>Time Event</b>	
Number of settings:	4 (Open collector output)
Output capacity:	24V DC 50mA or less
Pattern end signal:	1 (Open collector output)
Output capacity:	24V DC 50mA or less

<b>Environmental Condition</b>	
<b>Normal operating condition</b>	
Ambient Temperature:	0 to 50°C
Ambient Humidity:	20 to 90% R.H. (non-condensing)
Reference Junction:	
Temperature Compensation Error:	0 to 50°C: $\pm 1^{\circ}\text{C}$
Magnetic Field:	400 AT/m or less
Warm-up Time:	30 min or more
<b>Effects on operating conditions</b>	
Ambient Temperature Effect:	Input stability Within ( $\pm 1\mu\text{V}/^{\circ}\text{C}$ or $\pm 0.01\%/^{\circ}\text{C}$ , whichever is greater)
	Output stability Within (4 to 20mA DC) $\pm 0.05\%/10\text{V}$
Power Supply Variation:	Input stability Within ( $\pm 1\mu\text{V}/10\text{V}$ or $\pm 0.01\%/10\text{V}$ , whichever is greater)
	Output stability Within (4 to 20mA DC) $\pm 0.05\%/10\text{V}$
<b>Transmit/storage conditions</b>	
Temperature:	-25 to 70°C
Humidity:	5 to 95% R.H. (non-condensing)
<b>Construction, Dimensions, and Weight</b>	
Construction:	Dustproof, drip-proof construction (front panel)
Mounting:	Flash mounting
Case:	Plastic molding (ABS resin)
Dimension:	96W $\times$ 96H $\times$ 100D mm
Weight:	Approx. 1Kg

## General Specifications

Insulation resistance:	Between each terminal and ground: 20 MΩ or more at 500 V DC
Withstand voltage:	Between power terminals and ground: 1500V AC for 1 min Between input terminals and ground: 1000V AC for 1 min Between output terminals and ground: 1500V AC for 1 min
Supply voltage:	100 to 240V AC (universal power supply) (permissible supply voltage range: 90 to 250V AC)
Power frequency:	50/60 Hz common
Power consumption:	Approx. 12VA (100V)
Memory protection:	Nonvolatile memory

## Recovery from Power Failure

### Power failure of 2 sec or less

Instrument continues normal operation as if there were no power failure.

Alarm with standby action enters standby action

### Power failure of more than 2 sec

Alarm Alarm with standby action restart at the status of standby

Setting parameter Resistered

Auto-tuning Canceled

Control For RST = 0

Operation continues before power failure

Control output is preset output value

For RST = 1

Controller enters MAN mode

Control output applies preset output value

For RST = 2

Controller enters reset mode

Control output applies preset output value

If power failure occurs during setting using a key, error code 「**XX04**」 may appear.

# YOKOGAWA

---

## **YOKOGAWA ELECTRIC CORPORATION**

**TOKYO SALES OFFICE:** IZUMI HOSHI-ICHI Bldg.  
7-22-12 Nishi Shinjuku, Shinjuku-ku, Tokyo 160, JAPAN  
Phone: 81-3-5389-0940. Fax: 81-3-5389-5368

## **YOKOGAWA CORPORATION OF AMERICA**

2 Dart Road, Shenandoah Industrial Park, Newnan, GA 30265, U.S.A  
Phone: 404-253-7000. Fax: 404-251-2088

## **YOKOGAWA EUROPE B.V.**

Radiumweg 30, 3812 RA Amersfoort, THE NETHERLANDS  
Phone: (0)33-641611. Fax: (0)33-631202

---

## **CORPORATE HEADQUARTERS**

9-32, Nakacho 2-chome, Musashino-shi, Tokyo 180, JAPAN  
Phone: Tokyo 81-422-52-5565. Fax: 81-422-55-6549

---

Subject to change without notice

# YOKOGAWA

---

## YOKOGAWA ELECTRIC CORPORATION

### Headquarters

9-32, Nakacho 2-chome, Musashino-shi, Tokyo, 180 JAPAN  
Telex : 02822-327 YEW MT J

### Tokyo Office

Shinjuku Center Bldg. (50F)  
25-1, Nishi-shinjuku 1-chome, Shinjuku-ku, Tokyo, 163-06 JAPAN  
Phone : 03-3349-0611 Fax : 03-3348-3705  
Telex : J27584 YEW TOK

### Branch Sales Offices

Nagoya, Osaka, Hiroshima, Fukuoka, Sapporo, Sendai, Omiya,  
Ichihara, Kawasaki, Toyoda, Kanazawa, Kobe, Takamatsu,  
Okayama, and Kitakyusyu.

### Overseas Representative Offices / Service Centers

Beijing, Shanghai (The People's Republic of China), Jakarta  
(Indonesia)

---

## YOKOGAWA CORPORATION OF AMERICA

### Headquarters

2 Dart Road, Newnan, Ga. 30265-1094, U.S.A.  
Phone : 1-404-253-7000 Fax : 1-404-251-2088  
Telex : 230-244880 YCA

**Branch Sales Offices /** Chagrin Falls, Elk Grove Village, Santa  
Fe Springs, Hope Valley, Peachtree City, Houston

## JOHNSON YOKOGAWA CORPORATION

### Headquarters

4 Dart Road, Newnan, Ga. 30265-1040, U.S.A.  
Phone : 1-404-254-0400 Fax : 1-404-254-0928

**Branch Sales Offices /** Carrollton, Anaheim, Bensenville,  
Rutherford, Houston, Greenwood, Bartlesville, Carnegie

## YOKOGAWA EUROPE B. V.

### Headquarters

Radiumweg 30, 3812 RA Amersfoort, NETHERLANDS  
Phone : 31-33-641611 Fax : 31-33-631202  
Telex : 44-79118 YEF NL

**Branch Sales Offices /** Maarssen (Netherlands), Wien (Austria),  
Zaventem (Belgium), Ratingen (Germany), Madrid (Spain),  
Runcorn (United Kingdom), Milano (Italy)

## YOKOGAWA ELECTRICA DO BRASIL IND. E COM. LTDA.

Praca Acapulco, No.31 Parque Industrial Jurubatuba CEP 04675  
Santo Amaro - Sao Paulo, SP BRAZIL  
Phone : 55-11-548-2666 Telex : 38-1157755 YOKO BR  
Fax : 55-11-522-5231

## YOKOGAWA ELECTRIC ASIA PTE. LTD.

11 Tampines Street 92, Singapore 1852,  
SINGAPORE  
Phone : 65-783-9537 Fax : 65-786-2606  
Telex : RS-26137 YASSIN

## HANKUK YOKOGAWA ELECTRIC CO., LTD.

K.P.O.Box : 1481, Korean Reinsurance Bldg. 205,  
80 Susong-Dong, Chongro-ku, Seoul, KOREA  
Phone : 82-2-733-0771 to-0775 Fax : 82-2-739-3987

## YOKOGAWA AUSTRALIA PTY. LTD.

### Head Office

Private mail bag 24, Centre Court D3, 25-27 Paul Street  
North, North Ryde, N.S.W.2113, AUSTRALIA  
Phone : 61-2-805-0699 Fax : 61-2-888-1844

## YOKOGAWA BLUE STAR LTD.

### Headquarters

40/4 Lavelle Road Bangalore 560 001, INDIA  
Phone : 91-80-2211513 Fax : 91-80-2214270  
Telex : 81-8458702 YKCO IN

## YOKOGAWA CONTROLE BAILEY S. A.

5, avenue Newton, 92140 Clamart, FRANCE  
Phone : 33-1-46-29-10-00 Fax : 33-1-46-32-70-72  
Telex : 33-1-631 251