User's Manual

ADMAG TI Series
AXG Magnetic Flowmeter
BRAIN Communication Type

Manual Change No. 20-0005-E

Please add the following description to IM 01E22A02-01EN (3rd). As for method to confirm the device revision (indicator software revision), please refer to "4.10.2 Device Revision" on page 67.

Page/Section		Description
Page 12	2.3 Display Mode and Setting Mode	Follow the procedure bellow when Ind soft rev (K52:IND B REV / Ind soft rev) is R2.01.03 or later. **[Procedure]** 1) Keep touching [SET] switch for few seconds.  F0513.ai 2) Touch [SFT] + [INC] switches. F0514.ai 3) "No" is selected. Touch [INC] switch and select "Yes".  F0515.ai 4) Touch [SET] switch.  F0516.ai 5) "Yes" is blinking. Touch [SET] switch again.  F0517.ai 6) The screen moves to the menu of Operation Level.  F0518.ai 7) Select an appropreate operation level by moving the cursor with [INC] or [DEC] switch. Passcode is not necessary for "Operator". For "Maintenance" and "Specialist", passcode is necessary for each. For passcode setting, [SFT] is for position change, and [INC] is for number, then twice [SET] is for entry completion. The default passcode at the factory shipment is set to "0000".  F0519.ai 8) When the Operation Level is determined, the screen moves to "Device setup" as the Setting Mode where parameters can be configured. 9) After completing parameter setting, push [ESC] switch. The screen returns to the Display Mode.

YOKOGAWA
Yokogawa Electric Corporation

March 31, 2020