

Please consider this addendum to the referenced Instruction Manual below.

1. Applicable User's Manual and Page

IM No.	Edition	IM Title	Page	Applicable to section:
IM-P-20200627	1st	Hygienic & Sanitary Pressure Transmitter EJA565E	27	7.2 HART Commands and Parameters

2. Information to be replaced

The descriptions for the sections below supercede the referenced instruction manual information.

7.2 HART Commands and Parameters

Dynamic Variables (Command #3)		Note
PV	Pressure	Selected units (psi...mBar)
SV	Sensor Temperature	Selected units (Deg. F or C)
TV	Electronic Temperature	Selected units (Deg. F or C)
FV	(Pressure)	Same as PV

- Dynamic variables (PV,SV,TV,FV) and current can be read using HART Command #3.
- Device variables with Status can be read using HART Command #9.
- This product uses a HART Protocol equivalent, pending FieldComm Group (FCG) registration.