

FieldMate Revision-up Procedure

Contents

- 1. About Revision-up of FieldMate..... 2
- 2. Downloading Revision-up file and Update file 2
- 3. Revision-up procedure..... 5
 - 3.1. Preparation 5
 - 3.2. Revision-up..... 6
- 4. Update procedure 7
 - 4.1. Preparation 7
 - 4.2. Updating 7
 - 4.2.1. Updating FieldMate 7
 - 4.2.2. Updating DeviceFiles 7

1. About Revision-up of FieldMate

FieldMate is provided with two pieces of software. One is FieldMate software. The other is DeviceFiles software. Each software has Revision-up file and Update file. Revision-up file and Update file will be provided to FieldMate users on the Yokogawa FieldMate User site.

Note

Definition of Revision-up and Update in FieldMate are as follows:

Revision-up: Upgrading FieldMate software and DeviceFiles software at same time

Ex. R3.03.00 ⇒ R3.04.00

Update: To make FieldMate software or DeviceFiles software update by adding program


Ex. R3.04.00 ⇒ R3.04.02

2. Downloading Revision-up file and Update file

Revision-up file and Update file can be downloaded from FieldMate User site.

FieldMate/PRM/Device Files User site

<<https://partner.yokogawa.com/global/fieldmate/>>




Revision-up files consist of FieldMate software and DeviceFiles software.

Update files are provided for each of the FieldMate software and DeviceFiles software.

Note

- The Update file for FieldMate software is a cumulative file that contains the contents of update information issued so far. Therefore, you can complete the work just by applying the latest update file.
- The Update file for DeviceFiles software is an independent file that contains only the information of target devices. Therefore, it is necessary to apply in order from the old update file.

Please note that the Revision-up / Update file for FieldMate software and the Revision-up / Update file for DeviceFiles software are different in download location.



Note

In the case that “Information service/Download” page is not displayed

“Information service/Download” page can be accessed by only the user that registered FieldMate license. Please access again after FieldMate license registration if this page cannot be accessed.

The download page of FieldMate is shown below.

You can download the latest upgrade file and the latest update file of FieldMate from this page.

We recommend that your FieldMate is upgraded to the latest revision.

YOKOGAWA

Co-innovating tomorrow™

Partner Portal

Japan

Contact Us

Login ID

Logout

Home

FieldMate/PRM/Device Files User site

Information service/Download

FieldMate Information service/Download menu

FieldMate Information service/Download menu

You can download various electronic files from the following.

Update Information

Documents

Download	Explanation
<div><div></div><div>File name: FieldMate R3.04.02</div><div>Type: Update file</div><div>Size: 8,423KB</div><div>Date: 2019/02/18</div></div>	<div>[Operating Environment] - FieldMate Revision:R3.04.00</div> <div>[Contents] - Supported the connection to Signal Conditioner with BT200 tablet function. - Added the easy installation tool of DD file and the display function of the installed DD file list. - For Calibration Management for Liquid Analyzers, operability on small display has been improved. - For Provisioning Setting of ISA100 device, interoperability with 3rd vendor's devices has been improved. - Improved the communication between BRAIN DTM and BRAIN device.</div> <div>[Operation] - See the readme.txt.</div> <div>SHA256: 13E28A016603B18EA876DF6B284EB0648437FA6C58255E5ADEA4C26625F83B46</div>
<div><div></div><div>File name: FieldMate R3.04.00</div><div>Type: Revision-up file</div></div>	<div>[Contents] - Revision-up file for FieldMate R3.04.00</div> <div>[Operation] - See the User's Manual. - To execute Revision-up after downloading Device Files R3.09.00</div>

INF-FDV-T084

Rev.1

P.4

3. Revision-up procedure

3.1.Preparation

The revision-up of FieldMate software and DeviceFiles software are performed simultaneously.

1. Downloading the Revision-up file

Download the Revision-up file of FieldMate software and DeviceFiles software.

The downloaded files are as follows.

FieldMate software: FMUpdateR*****.zip (*: Revision number)

DeviceFiles software: DeviceFilesR*.*.zip (*: Revision number)

2. Extract the downloaded files

The following folders are created when each file is extracted.

FieldMate software: FMUpdateR*****.zip → "FMR*****" folder

There is the subfolder "Disk1".

DeviceFiles software: DeviceFilesR*.*.zip → "DFR*****" folder


There is the subfolder "Disk2".

3. Move folders


Move each folder under C drive.

3.2. Revision-up

1. Execute "\\Disk1\FM\setup.exe" in the "FMR *****" folder (revision-up file of FieldMate software) moved to the C drive as an administrator.
2. During installation, a dialog box appears asking to insert the FieldMate Device Files DVD-ROM. Enter the path of "Disk2" folder in "DFR *****" folder (revision-up file of DeviceFiles software) moved to the C drive.



3. Upgrading is finished After reboot PC.
4. The current revision can be confirmed at "About FieldMate" dialog.



4. Update procedure

4.1. Preparation

1. Downloading the Update file

Download the Update file of FieldMate software or DeviceFiles software.

The downloaded files are as follows.

FieldMate software: FMUpdateR*****.zip (*: Revision number)

DeviceFiles software: DeviceFilesR*.*.zip (*: Revision number)

2. Extract the downloaded file

Extract the downloaded file to any folder.

3. Move folder

Move the folder under C drive.

4.2. Updating

4.2.1. Updating FieldMate software

There is a "***_Readme.txt" file (**: JP for Japanese, EN for English) in the extracted files. Please execute the update according to follow the procedure described in this text file.

4.2.2. Updating DeviceFiles software

Execute "FMPRMDeviceFiles.exe" as an administrator.