


Drawings

Model FTF Power Distributor Unit (with Fuse)


SD JF83-05E

Unit: mm

<FTF-16 External Dimension>



<FTF-08 External Dimension>



<FTF-04 External Dimension>

