



DX2000/DX1000/DX1000N Temp Unit Change

Tech note TN12002

- ❖ This tech note explains how to change the temperature unit of the DXA from degrees Celsius to degrees Fahrenheit
- ❖ The DXA is shipped from the factory set for degrees Celsius, and this Tech note can be used to change from $^{\circ}\text{C}$ to $^{\circ}\text{F}$, or from $^{\circ}\text{F}$ to $^{\circ}\text{C}$
- ❖ Refer to the main User Manual for your DXA model for more information on all functions and settings

❖ 1. Go to Basic setting mode

- ❖ Press **MENU** key
 - Hold **FUNC** key for 3 seconds
- ❖ Select **Environment** tab
- ❖ Select **Operating Environment** to get to Temperature.
 - Highlight the temperature unit.
 - With the temp unit highlighted you can now select the soft key for **C** or **F**.
 - Press the enter key two times, making sure the temp unit box is not yellow.
 - Press ESC two times, select yes to store the new settings. The unit will reboot, and the temp is set.



Thank you!