
Technical Information

UTAdvanced UP35A Program Controller Parameter Maps and Lists

UTAdvanced

YOKOGAWA ♦

TI 05P02D41-01EN
©Copyright July. 2011
1st Edition July. 2011

UTAdvanced UP35A

Introduction

Brief Description of Sheets

This sheet provides a brief description of the following sheets entitled "Names and Functions of Display Parts," "Operation and Program Parameter Map," "Setup Parameter Map," "List of Parameters," "Program Data Sheet," and "Example."

"Names and Functions of Display Parts"

This sheet describes the names and functions of display parts, function of parameter display level, meaning of parameter map symbol and numeric value, parameter display transition and setup operation, and display symbol list.

"Operation Map (PRO)"

This sheet describes the operation parameter map, which can be used as an operation guide.

"Setup Map (PRO)"

This sheet describes the setup parameter map, which can be used as an operation guide.

"List of Parameters (SGL_PRO)"

This sheet describes the setting range and initial value of operation parameters and setup parameters. There is a column for user settings.

"Program Data Sheet"

This sheet can be used for recording the setting value or creating the program pattern.

"Example"

This sheet describes an example of simply program pattern.

Parameters in the sheets are displayed when the parameter display level is set to professional setting mode (LEVL=PRO). Some parameters are not displayed according to model and suffix codes. For details, refer to the User's Manual.

Operation and Program Parameters: Parameters for setting the functions necessary for the operation and Parameters for creating the program pattern.

Setup Parameters: Parameters for setting the basic functions of the controller.

Notice

The contents of this manual are subject to change without notice as a result of continuing improvements to the instrument's performance and functions.

UTAdvanced UP35A


Names and Functions of Display Parts

UP35A Display Parts



No. in figure	Name	Description
(1)	PV display (white or red)	Displays PV. Displays an error code if an error occurs. Displays the scrolling guide in the Menu Display and Parameter Setting Display when the guide display ON/OFF is set to ON.
(2)	Group display (pattern number) (green)	1 to 2 (4 when the option "/AP" is specified) represent pattern numbers in the Operation Display. Displays a group number (1 to 4 or R) and terminal area (E1 to E4) in the Parameter Setting Display.
(3)	Symbol display (orange)	Displays a parameter symbol.
(4)	Data display (orange)	Displays a parameter setpoint and menu symbol.
(5)	Bar-graph display (event, alarm) (orange)	Displays the event status and the segment position in the Operation Display. (Default values: Time event status, Alarm status) Displays control output value (OUT) and measured input value (PV). The data to be displayed can be set by the parameter.
(6)	Event indicator (orange)	Lit when the PV events occur. Event displays can be set by the parameter.
(7)	Key navigation indicator (green)	Lit or blinks when the Up/Down or Left/Right arrow key operation is possible.
(8)	Parameter display level indicator (green)	Displays the setting conditions of the parameter display level function. Parameter display level EASY PRO Easy setting mode Lit Unlit Standard setting mode Unlit Unlit Professional setting mode Unlit Lit
(9)	Program monitor (green)	Displays the status of increment, constancy, and decrement of the program setpoint. : Lit when a program setpoint is increasing. : Lit when a program setpoint is constant. : Lit when a program setpoint is decreasing.
(10)	Status indicator (green and red)	Displays the operating conditions and control status. Display Description HLD Lit when in remote mode (HOLD). PRG Lit when in program operation mode (PRG). Lit while the Starting time of program operation (S.TM) is available. RST Lit when in reset mode (RST). MAN Lit when in manual mode (MAN). Blinks during auto-tuning.
(11)	Security indicator (red)	Lit if a password is set. The setup parameter settings are locked.
(12)	Ladder operation indicator (green)	Lit while the ladder program operation is executed.

UP35A Key Parts



No. in figure	Name	Description
(1)	DISPLAY key	Used to switch the Operation Displays. Press the key in the Operation Display to switch the provided Operation Displays. Press the key in the Menu Display or Parameter Setting Display to return to the Operation Display.
(2)	PARAMETER key	Hold down the key for 3 seconds to move to the Operation Parameter Setting Display. Hold down the key and the Left arrow key simultaneously for 3 seconds to move to the Setup Parameter Setting Display. Press the key in the Parameter Setting Display to return to the Menu Display. Press the key once to cancel the parameter setting (setpoint is blinking).
(3)	SET/ENTER key Up/Down/ Left/Right arrow keys	SET/ENTER key Press the key in the Menu Display to move to the Parameter Setting Display of the Menu. Press the key in the Parameter Setting Display to transfer to the parameter setting mode (setpoint is blinking), and the parameter can be changed. Press the key during parameter setting mode to register the setpoint. Up/Down/Left/Right arrow keys Press the Left/Right arrow keys in the Menu Display to switch the Displays. Press the Up/Down/Left/Right arrow keys in the Parameter Setting Display to switch the Displays. Press the Up/Down arrow keys during parameter setting mode (setpoint is blinking) to change a setpoint. Press the Left/Right arrow keys during parameter setting mode (setpoint is blinking) to move between digits according to the parameter.
(4)	Light-loader interface	It is the communication interface to the adapter cable when setting and storing parameters via PC. The LL50A Parameter Setting Software (sold separately) is required.
(5)	RUN key RST key MODE key PTN key	PTN key: Press the RUN key for 1 second while an operation display is shown starts the controller. RST key: Press the RST key for 1 second while an operation display is shown stops the controller. MODE key: Presents a display for switching between the HOLD, ADVANCE, PROG, RESET, LOCAL and AUTO/MAN. In order to change the operation mode, press the SET/ENTER key while the setpoint is blinking. PTN key: A program pattern number can be selected during the operation except the program pattern operation. (The program pattern number displayed on the Group display blinks.) When the PTN key is pressed while the program pattern number is blinking, the blinking stops. Users can assign functions to the key using parameters.

Brief Description of Parameter Map


The parameter display level is a function to control the parameters to be displayed. The factory setting is LEVL=STD.

The control prevents unintentional change of the function.


The parameter display level is just a function to hide the display so the set function works.

Changing of parameter display level

The parameters to be displayed can be controlled by changing the setting value for setup parameter LEVL.



Meaning of Parameter Symbol and Numeric Value



Group E1: indicates the parameter in E1-terminal area
E3: indicates the parameter in E3-terminal area
E4: indicates the parameter in E4-terminal area
1 to 4, R: indicate the group numbers

Display may be controlled according to the setting value of the setup parameter and operation status.

Parameter Display Transition and Setup Operation

To move to the Operation Parameter Setting Display



Press the key
for 3 seconds.

To move to the Setup Parameter Setting Display



+ Press the key
for 3 seconds.

To move to the Operation Display

If you cannot remember how to carry out an operation during setting, press the DISPLAY key once. This brings you to the display (Operation Display) that appears at power-on.




<Operation for Setting>

To select the parameter setting displayed as the initial value, press the Down arrow key to move to the next parameter.


To change and set the parameter setting, press the SET/ENTER key to start the setpoint blinking. The blinking state allows you to make changes (setting mode). Use the Up/Down/Left/Right arrow keys to change the setpoint. Press the SET/ENTER key to register the setting.

The following operating procedure describes an example of setting alarm setpoint (A1)

1. Hold down the PARAMETER key for 3 seconds in the Operation Display to call up the [MODE] Menu Display.




2. Press the Right arrow key to display the [AL] Menu Display.



3. Press the SET/ENTER key to display the [A1] Parameter Setting Display.




4. Press the SET/ENTER key to blink the setpoint.



5. Press the Up or Down arrow key to change the setpoint.

(Change the setpoint using the Up/Down arrow keys to increase and decrease the value and the Left/Right arrow keys to move between digits.)



6. Press the SET/ENTER key to register the setpoint (the setpoint stops blinking).



7. Press the PARAMETER key once to return to the Menu Display. Press the DISPLAY key once to return to the Operation Display.

This completes the setting procedure.

How to Cancel Parameter Setting

To cancel parameter setting when a parameter is being set (setpoint is blinking), press the PARAMETER key once.

How to Set Parameter Setpoint

Numeric Value Setting



R I 7940

R I 7940

R I 7940

R I 8040

R I 8040

1. Display the Parameter Setting Display.
2. Press the SET/ENTER key to move to the setting mode (the setpoint blinks).
3. Press the Left arrow key to move one digit to the left.(Press the Right arrow key to move one digit to the right.)
4. Press the Up or Down arrow key to change the setpoint. Press the Up arrow key when 9 is displayed to move one digit to the left. Press the Down arrow key when 0 is displayed to move one digit to the right.
5. Press the SET/ENTER key to register the setpoint.

Selection Data Setting



HOLD OFF

HOLD OFF

HOLD ON

HOLD ON

1. Display the Parameter Setting Display.
2. Press the SET/ENTER key to move to the setting mode (the setpoint blinks).
3. Press the Up arrow key to change the setpoint (press the Down arrow key to change the setpoint).
4. Press the SET/ENTER key to register the setpoint.

Time (minute.second) Setting



Example of 17 minutes 59 seconds

dYN 1 1759

dYN 1 1759

dYN 1 1759

dYN 1 1809

dYN 1 1809

1. Display the Parameter Setting Display.
2. Press the SET/ENTER key to move to the setting mode (the setpoint blinks).
3. Press the Left arrow key to move one digit to the left.(press the Right arrow key to move one digit to the right.)
4. Press the Up or Down arrow key to change the setpoint. Press the Up arrow key when 5 is displayed to move one digit to the left. Press the Down arrow key when 0 is displayed to move one digit to the right.
5. Press the SET/ENTER key to register the setpoint.

List of Display Symbols

The following shows the parameter symbols, menu symbols, alphanumeric of guide, and symbols which are displayed on the UP35A.

Figure (common to all display area)

0 1 2 3 4 5 6 7 8 9

PV display (14 segments): Alphabet

A	B	C	D	E	F
G	H	I	J	K	L
M	N	O	P	Q	R
S	T	U	V	W	X
Y	Z				

Symbol display and Data display (11 segments): Alphabet

A	B	C	D	E	F
C (lower-case)					
C					
G	H	I	J	K	L
M	N	O	P	Q	R
S	T	U	V	W	X
Y	Z				

Group display (7 segments): Alphabet

A	B	C	D	E	F
G	H	I	J	K	L
M	N	O	P	Q	R
S	T	U	V	W	X
Y	Z				

None


PV display (14 segments): Symbol

Space - / , ;

UTAdvanced UP35A

Operation and Program Parameter Map



* Some parameters are not displayed according to the model and suffix codes or the setting of CNT parameter. For details, refer to the User's Manual.



UTAdvanced UP35A

Setup Parameter Map

* Some parameters are not displayed according to model and suffix codes or the setting of CNT parameter. For details, refer to the User's Manual.



UTAdvanced UP35A

List of Parameters

* Some parameters are not displayed according to the model and suffix codes or the setting of CNT parameter. For details, refer to the User's Manual.

Operation and Program Parameters

Operation Mode

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
MODE	HOLD	Pause/cancel release of program operation	EASY	ON: Pause OFF: Cancel release (Program operation restart) Display during program operation.	OFF	
	ADV	Advance of segment	EASY	OFF: - Display during program operation. Set as "ADV = ON" to advance from the current segment to the next segment.	OFF	
	MODE	Operation mode	EASY	RESET: Stop of program operation PROG: Start of program operation LOCAL: Start of local-mode operation	RESET	
	A.M	AUTO/MAN switch	EASY	AUTO: Automatic mode MAN: Manual mode	MAN	
	PTNO.	Program pattern number selection	EASY	0: Not select program pattern 1 to 2 (4 when the option "/AP" is specified.)	0	
	SST	Start-of-program segment number	EASY	1 to 20 (40 when the option "/AP" is specified.) The setting value returns to "1" when the program operation (PROG) changes into RESET or LOCAL.	1	
	P.FWD	Fast-forwarding of program operation	EASY	1: Normal, 2: Twice, 5: Five times, 10: Ten times, 20: Twenty times * Use this function when checking the program pattern setting. Only Segment time and Time event can be faster. * The operation returns to the normal speed after fast-forwarding.	1	
	AT	Auto-tuning switch	EASY	OFF: Disable 1 to 4: Perform auto-tuning. Tuning result is stored in the specified numbered PID. R: Tuning result is stored in the PID for reference deviation.	OFF	
	PID	PID number	EASY	The PID group number being selected is displayed. (display only) 1 to 4, R: PID group for reference deviation	1	

SELECT Parameter

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
CS	CS10	SELECT parameter 10	EASY	-	-	
	CS11	SELECT parameter 11	EASY	-	-	
	CS12	SELECT parameter 12	EASY	-	-	
	CS13	SELECT parameter 13	EASY	-	-	
	CS14	SELECT parameter 14	EASY	-	-	
	CS15	SELECT parameter 15	EASY	-	-	
	CS16	SELECT parameter 16	EASY	-	-	
	CS17	SELECT parameter 17	EASY	-	-	
	CS18	SELECT parameter 18	EASY	-	-	
	CS19	SELECT parameter 19	EASY	-	-	
	Setting range of a registered parameter. See User's Manual.					

Program Pattern Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
PROG>SEGNO.	SSP	Starting target setpoint	EASY	0.0 to 100.0% of PV input range (EU) (Setting range: P.RL to P.RH)	P.RL	See Sheet "Program Data Sheet"
	STC	Start code	EASY	SSP: Program operation begins with the starting target setpoint. RAMP: Ramp-prioritized PV start TIME: Time-prioritized PV start LSP: Local-mode start * STC=TIME cannot be selected when the parameter SEG.T is TM.RT.	SSP	See Sheet "Program Data Sheet"
	WT.SW1	Wait function ON/OFF	STD	OFF: Disable ON: Enable	OFF	See Sheet "Program Data Sheet"
	WZ.UP1	Upper-side wait zone	STD	0.0 to 10.0% of PV input range (EU)	0.5% of PV input range	See Sheet "Program Data Sheet"
	WZ.LO1	Lower-side wait zone	STD		0.5% of PV input range	See Sheet "Program Data Sheet"
	WT.TM1	Wait time	STD	OFF: No function 0.00 to 999.59 ("hour.minute" or "minute.second") * Available only for the wait time at the segment switching. * Use the parameter TMU to set the time unit. (Common in the instrument.)	OFF	See Sheet "Program Data Sheet"
	R.CYCL	Number of repeat cycles	STD	0 to 999, CONT (The controller indefinitely repeats the segment specified by the R.START and R.END parameters.)	0	See Sheet "Program Data Sheet"
	R.START	Repeat cycle start segment number	STD	1 to 20 (40 when the option "/AP" is specified.) 1 ≤ R.START ≤ R.END ≤ 20 (40)	1	See Sheet "Program Data Sheet"
	R.END	Repeat cycle end segment number	STD		1	See Sheet "Program Data Sheet"

Program Pattern Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
PROG>PTNO.	TSP	Final target setpoint	EASY	0.0 to 100.0% of PV input range (EU) (Setting range: P.RL to P.RH)	P.RL	See Sheet "Program Data Sheet"
	TIME	Segment time setting	EASY	:- Unregistered 0.00 to 999.59 ("hour.minute" or "minute.second") * Setting available for the parameter SEG.T=TIME. * Use the parameter TMU to set the time unit. (Common in the instrument.) * If the setting is 0.00, TSP changes in stepwise after one control period.	-	See Sheet "Program Data Sheet"
	TM.RT	Segment ramp-rate setting	EASY	:- Unregistered Ramp: 0.0 to 100.0% of PV input range span (EUS) / 1 hour or 1 minute Soak: 0.00 to 999.59 ("hour.minute" or "minute.second") * Setting available for the parameter SEG.T=TM.RT. * Use the parameter TMU to set the time unit. (Common in the instrument.) Per 1 hour: TMU=HH:MM, Per 1 minute: TMU=MM:SS * If it is set to 0.0% of the input range span, or the segment time 0.00, the program moves to the next segment after one control period.	-	See Sheet "Program Data Sheet"
	S.PID	Segment PID number selection	EASY	1 to 4 * PID number can be set when the parameter "ZON = 0."	1	See Sheet "Program Data Sheet"
	JC	Junction code	STD	CONT: Switching for continuation HOLD: Hold-on switching (the controller holds the end-of-segment setpoint when the segment is completed, to perform control). LOCAL: Local-mode switching (the controller switches to a local setpoint when the segment is completed). W.SW: Wait during switching between segments. W.IV: Wait within a segment interval. W.SL: Segment switching (the controller switches to a local setpoint when the segment is completed after release.) (5 groups) PLK.1 to PLK.2 (PLK.4 when the option "/AP" is specified.): Linked to patterns 1 to 2 (4.) INS.: Allows a segment to be added to the end of a specified segment. DEL.: Allows a specified segment to be deleted.	CONT	See Sheet "Program Data Sheet"
	PV.TY1~PV.TY2	PV event-1 to -2 type	STD	OFF: Disable (Energized) 1: PV high limit, 2: PV low limit, 3: SP high limit, 4: SP low limit, 5: Deviation high limit, 6: Deviation low limit, 7: Deviation high and low limits, 8: Deviation within high and low limits, 9: Target SP high limit, 10: Target SP low limit, 11: Target SP deviation high limit, 12: Target SP deviation low limit, 13: Target SP deviation high and low limits, 14: Target SP deviation within high and low limits, 15: OUT high limit, 16: OUT low limit, 17: Cooling-side OUT high limit, 18: Cooling-side OUT low limit * Add 100 for "de-energized". For example, when the PV high limit is de-energized, the setting is 101.	OFF	See Sheet "Program Data Sheet"
	PV.EV1~PV.EV2	PV event-1 to -2 setpoint	STD	Set a display value of setpoint of PV alarm, SP alarm, deviation alarm, or output alarm. -19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type.	0	See Sheet "Program Data Sheet"
	TME1~TME4	Start condition of time event 1 to 4	STD	ON: Start ON state OFF: Start OFF state	OFF	See Sheet "Program Data Sheet"
	T.ON1~T.ON4	On time of time event 1 to 4	STD	:- Unregistered 0.01 to 999.59 ("hour.minute" or "minute.second") * Available only within the segment time.	-	See Sheet "Program Data Sheet"
	T.OF1~T.OF4	Off time of time event 1 to 4	STD	OFF when the operation mode is changed to the mode except the program operation. * Use the parameter TMU to set the time unit. (Common in the instrument.)	-	See Sheet "Program Data Sheet"

Local Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
LOC	LSP	Local target setpoint	EASY	0.0 to 100.0% of PV input range (EU) (Setting range: P.RL to P.RH)	P.RL	
	L.PID	PID number selection for local mode operation	EASY	Set a PID group number to use. 1 to 4 * Available only for the L.PID when ZON = 0 or 5. * If set to "Local PID selection," local PID is selected irrespective of the operation modes.	1	
	L.TY1	Local event-1 type	STD	OFF: Disable (Energized) 1: PV high limit, 2: PV low limit, 3: SP high limit, 4: SP low limit, 5: Deviation high limit, 6: Deviation low limit, 7: Deviation high and low limits, 8: Deviation within high and low limits, 9: Target SP high limit, 10: Target SP low limit, 11: Target SP deviation high limit, 12: Target SP deviation low limit, 13: Target SP deviation high and low limits, 14: Target SP deviation within high and low limits, 15: OUT high limit, 16: OUT low limit, 17: Cooling-side OUT high limit, 18: Cooling-side OUT low limit * Add 100 for "de-energized". For example, when the PV high limit is de-energized, the setting is 101.	OFF	
	L.EV1	Local event-1 setpoint	STD	Set a display value of setpoint of PV alarm, SP alarm, deviation alarm, or output alarm. -19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type	0	
	L.TY2	Local event-2 type	STD	Same as L.TY1	OFF	
	L.EV2	Local event-2 setpoint	STD	Same as L.EV1	0	

Program Editing

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
EDIT	ALL.S	Number of remaining unused segments	PRO	0 to 20 (40 when the option "/AP" is specified.) (Display only)	20 (40)	
	PTN.S	Pattern number designation for confirming number of segments	PRO	Specify the numbers of program pattern to display in parameter USE.S. 1 to 2 (4 when the option "/AP" is specified.)	0	
	USE.S	Number of segments within a pattern	PRO	Can be displayed when the parameter number specify in parameter PTN.S. (Display only) 0: disable 1 to 20 (40 when the option "/AP" is specified.)	-	
	CPY.S	Source-of-copying pattern number designation	PRO	Specify the number of the source-of-copying program pattern. (1 to 2 (4 when the option "/AP" is specified.))	0	
	CPY.D	Target-of-copying pattern number designation	PRO	Specify the target-of-copying program pattern. (1 to 2 (4 when the option "/AP" is specified.))	0	
	CLR.P	Program pattern clearance	PRO	Specify the number of the program pattern to be cleared. (1 to 2 (4 when the option "/AP" is specified.))	0	

Alarm Setpoint Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
AL	A1	Alarm-1 setpoint	EASY	These alarms work irrespective of the operation mode. Set a display value of setpoint of PV alarm, SP alarm, deviation alarm, output alarm, or velocity alarm.	0	
	A2	Alarm-2 setpoint	EASY	-19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type.	0	

SP-related Setting




Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
SPS	SPT	SP tracking selection	STD	OFF, ON Tracking is performed when the mode changes from Program to Local. (The local setpoint keeps track of the program setpoint.)	OFF	
	S.TM	Starting time of program operation	STD	0.00 to 999.59 (hour.minute) or minute.second (common use of instrument) * Use the parameter TMU to set the time unit.	0.00	
	PNC	Program pattern number clearance	STD	OFF: Not cleared. ON: Cleared. (Set the program No. before restart program operation) * The controller resets (clears) the program pattern number on the operating display to "0" at the end of program operation.	OFF	

Alarm Function Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
ALRM	EHY1	Event-1 hysteresis	STD	The hysteresis setpoint of PV event or Local event is set to the percentage of 0.0 to 100.0%.	0.5%	
	EHY2	Event-2 hysteresis	STD	The setting value (%) is for the PV input range span or output span.	0.5%	
	AL1	Alarm-1 type	EASY	These alarms work irrespective of the operation mode. Set a 5-digit value in the following order. [Alarm type: 2 digits (see below)] + [Without (0) or With (1) Stand-by action] + [Energized (0) or De-energized (1)] + [Latch action (0/1/2/3/4)] Alarm type: 2 digits 00: Disable 01: PV high limit 02: PV low limit 03: SP high limit 04: SP low limit 05: Deviation high limit 06: Deviation low limit 07: Deviation high and low limits 08: Deviation within high and low limits 09: Target SP high limit 10: Target SP low limit 11: Target SP deviation high limit 12: Target SP deviation low limit 13: Target SP deviation high and low limits 14: Target SP deviation within high and low limits 15: OUT high limit 16: OUT low limit 17: Cooling-side OUT high limit 18: Cooling-side OUT low limit 19: Analog input PV high limit 20: Analog input PV low limit 27: Feedback input high limit 28: Feedback input low limit 29: PV velocity 30: Fault diagnosis 31: FAIL	PV high limit (01) Without Standby action (0) Energized (0) Latch action (0)	
	AL2	Alarm-2 type	EASY	PV low limit (02) Without Standby action (0) Energized (0) Latch action (0)		
	VT1	PV velocity alarm time setpoint 1	EASY		1.00	
	VT2	PV velocity alarm time setpoint 2	EASY	0.01 to 99.59 (minute.second)	1.00	
	HY1	Alarm-1 hysteresis	EASY	Set a display value of setpoint of hysteresis. -19999 to 30000 (Set a value within the input range.) Decimal point position depends on the input type.	10	
	HY2	Alarm-2 hysteresis	EASY	When the decimal point position for the input type is set to "1", the initial value of the hysteresis is "1.0".	10	
	DYN1	Alarm-1 On-delay timer	STD		0.00	
	DYN2	Alarm-2 On-delay timer	STD	0.00 to 99.59 (minute.second)	0.00	
	DYF1	Alarm-1 Off-delay timer	PRO	0.00 to 99.59 (minute.second)	0.00	
	DYF2	Alarm-2 Off-delay timer	PRO	0.00 to 99.59 (minute.second)	0.00	
	AMD	Alarm mode	STD	0: Always active 1: Not active in RESET mode 2: Not active in MAN mode	0	

PV-related Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
PVS	BS	PV input bias	EASY	-100.0 to 100.0% of PV input range span (EUS)	0.0 % of PV input range span	
	FL	PV input filter	EASY	OFF, 1 to 120 s	OFF	



PID Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting	User setting	User setting	User setting
Group 1 (S.PID=1) Group 2 (S.PID=2) Group 3 (S.PID=3) Group 4 (S.PID=4)									
PID	P	Proportional band Heating-side proportional band (in Heating/cooling control)	EASY	0.0 to 999.9% When 0.0% is set, it operates as 0.1%.	5.0%				
	I	Integral time Heating-side integral time (in Heating/cooling control)	EASY	OFF: Disable 1 to 6000 s	240 s				
	D	Derivative time Heating-side derivative time (in Heating/cooling control)	EASY	OFF: Disable 1 to 6000 s	60 s				
	OH	Control output high limit Heating-side control output high limit (in Heating/cooling control)	EASY	-4.9 to 105.0%, (OL<OH) In Heating/cooling control: 0.1 to 105.0% (OL<OH)	100.0%				
	OL	Control output low limit Heating-side control output low limit (in Heating/cooling control)	EASY	-5.0 to 104.9%, (OL<OH), SD-Tight shut In Heating/cooling control: 0.0 to 104.9% (OL<OH)	0.0%				
	MR	Manual reset	EASY	Enabled when integral time is OFF. The manual reset value equals the output value when PV = SP. -5.0 to 105.0%	50.0%				
	HYS	Hysteresis (in ON/OFF control, or Position proportional control) Heating-side ON/OFF control hysteresis (in Heating/cooling control)	EASY	In ON/OFF control: 0.0 to 100.0% of PV input range span (EUS) In Heating/cooling control or Position proportional control: 0.0 to 100.0%	In ON/OFF control: 0.5 % of PV input range span In Heating/cooling control or Position proportional control: 0.5 %				
	HY.UP	Upper-side hysteresis (in ON/OFF control)	EASY	0.0 to 100.0% of PV input range span (EUS)	0.5 % of PV input range span				
	HY.LO	Lower-side hysteresis (in ON/OFF control)	EASY		0.5 % of PV input range span				
	DR	Direct/reverse action switch	STD	RVS: Reverse action, DIR: Direct action	RVS				
	Pc	Cooling-side proportional band	EASY	0.0 to 999.9% (Cooling-side ON/OFF control applies when 0.0% in Heating/cooling control)	5.0%				
	Ic	Cooling-side integral time	EASY	OFF: Disable 1 to 6000 s	240 s				
	Dc	Cooling-side derivative time	EASY	OFF: Disable 1 to 6000 s	60 s				
	OHc	Cooling-side control output high limit	EASY	0.1 to 105.0%, (OLc<OHc)	100.0%				
	OLc	Cooling-side control output low limit	EASY	0.0 to 104.9%, (OLc<OHc)	0.0%				
	HYSc	Cooling-side ON/OFF control hysteresis	EASY	0.0 to 100.0%	0.5%				
	DB	Output dead band (in Heating/cooling control or Position proportional control)	EASY	In Heating/cooling control: -100.0 to 50.0% In Position proportional control: 1.0 to 10.0%	3.0%				
	PO	Preset output Heating-side preset output (in Heating/cooling control)	EASY	-5.0 to 105.0% In RESET mode, fixed control output can be generated. In Position proportional control, Valve opening can be set	0.0%				
	POc	Cooling-side preset output	EASY	-5.0 to 105.0% In RESET mode, cooling-side fixed control output can be generated.	0.0%				

Tuning

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting	
TUNE	SC	Super function	EASY	OFF: Disable 1: Overshoot suppressing function (normal mode) 2: Hunting suppressing function (stable mode) Enables to answer the wider characteristic changes compared with response mode. 3: Hunting suppressing function (response mode) Enables quick follow-up and short converging time of PV for the changed SP. 4: Overshoot suppressing function (strong suppressing mode) Note: Setpoints 2 and 3 must be used in PID control or PI control. Disabled in the following controls: 1) ON/OFF control, 2) PD control, 3) P control, 4) Heating/cooling control. Do not use the function for the control processes with response such as flow or pressure control	OFF		
	AT.TY	Auto-tuning type	STD	0: Normal 1: Stability	0		
	AT.OH	Output high limit in auto-tuning	PRO	-5.0 to 105.0% (Disabled in Heating/cooling control)	100.0%		
	AT.OL	Output low limit in auto-tuning	PRO		0.0%		
	AT.BS	SP bias in autotuning	PRO	-100.0 to 100.0% of PV input range span (EUS)	0.0% of PV input range span		
	AR	Anti-reset windup (excess integration prevention)	STD	AUTO, 50.0 to 200.0%	AUTO		
	OPR	Output velocity limiter	STD	OFF: Disable 0.1 to 100.0%/s	OFF		
	OLMT	Output limiter switch	PRO	OFF: Disable output limiter in MAN mode ON: Enable output limiter in MAN mode	ON		
	MPON	Manual preset output number selection	STD	OFF: Hold the control output in AUTO mode (bumpless) 1: Use manual preset output 1 (output bump) 2: Use manual preset output 2 (output bump) 3: Use manual preset output 3 (output bump) 4: Use manual preset output 4 (output bump) 5: Use manual preset output 5 (output bump)	OFF		
	MPO1	Manual preset output 1	STD		0.0%		
	MPO2	Manual preset output 2	STD		0.0%		
	MPO3	Manual preset output 3	STD		0.0%		
	MPO4	Manual preset output 4	STD		0.0%		
	MPO5	Manual preset output 5	STD	* However, output is limited to the output high limit and low limit.	0.0%		

Zone Control

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
ZONE	RP1	Reference point 1	STD	0.0 to 100.0% of PV input range (EU) (RP1 ≤ RP2 ≤ RP3)	100.0 % of PV input range	
	RP2	Reference point 2	STD	* Set reference points at which switching is carried out between groups of PID constants according to the given temperature zone.	100.0 % of PV input range	
	RP3	Reference point 3	STD		100.0 % of PV input range	
	RHY	Zone PID switching hysteresis	STD	0.0 to 10.0% of PV input range span (EUS) * Hysteresis can be set for switching at a reference point.	0.5 % of PV input range span	
	RDV	Reference deviation	STD	OFF: Disable 0.0 + 1 digit to 100.0% of PV input range span (EUS) * Set a deviation from SP. The PID for reference deviation is used if there is a larger deviation than the preset reference deviation.	OFF	

P Parameter

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
PPAR	P01	P01 Parameter	STD		0	
	P02	P02 Parameter	STD		0	
	P03	P03 Parameter	STD		0	
	P04	P04 Parameter	STD		0	
	P05	P05 Parameter	STD	-19999 to 30000 (Set a decimal point position using LL50A Parameter Setting Software.)	0	
	P06	P06 Parameter	STD		0	
	P07	P07 Parameter	STD		0	
	P08	P08 Parameter	STD		0	
	P09	P09 Parameter	STD		0	
	P10	P10 Parameter	STD		0	

Setup Parameters

Control Function Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
CTL	CNT	Control type	EASY	PID: PID control ONOF: ON/OFF control (1 point of hysteresis) ONOF2: ON/OFF control (2 points of hysteresis) H/C: Heating/cooling control	Standard type: PID Heating/cooling type: H/C	
	ALG	PID control mode	PRO	0: Standard PID control mode 1: Fixed-point control mode	0	
	ALNO.	Number of alarms	PRO	1 to 2	2	
	ZON	Zone PID selection	STD	0: Segment PID selection 1: Zone PID selection (selection by PV) 2: Zone PID selection (selection by target SP) 4: Zone PID selection (selection by SP) 5: Local PID selection * If set to "Segment PID selection," allows PID constants to be selected for each segments. * If set to "Zone PID selection," automatically selects PID constants according to the range set in the Reference point. * If set to "Local PID selection," local PID is selected irrespective of the operation modes.	1	
	SEG.T	Segment setting method	EASY	TIME: Segment time setting TM.RT: Segment ramp-rate setting Note: A change of setting deletes a program pattern.	TIME	
	TMU	Program time unit	EASY	HH.MM: hour.minute MM.SS: minute.second	HH.MM	

PV Input Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
PV	IN	PV input type	EASY	OFF: Disable K1: -270.0 to 1370.0 (°C) / -450.0 to 2500.0 (°F) K2: -270.0 to 1000.0 (°C) / -450.0 to 2200.0 (°F) K3: -200.0 to 500.0 (°C) / -200.0 to 1000.0 (°F) J: -200.0 to 1200.0 (°C) / -300.0 to 2300.0 (°F) T1: -270.0 to 400.0 (°C) / -450.0 to 750.0 (°F) T2: 0.0 to 400.0 (°C) / -200.0 to 750.0 (°F) B: 0.0 to 1800.0 (°C) / 32 to 3300 (°F) S: 0.0 to 1700.0 (°C) / 32 to 3100 (°F) R: 0.0 to 1700.0 (°C) / 32 to 3100 (°F) N: -200.0 to 1300.0 (°C) / -300.0 to 2400.0 (°F) E: -270.0 to 1000.0 (°C) / -450.0 to 1800.0 (°F) L: -200.0 to 900.0 (°C) / -300.0 to 1600.0 (°F) U1: -200.0 to 400.0 (°C) / -300.0 to 750.0 (°F) U2: 0.0 to 400.0 (°C) / -200.0 to 1000.0 (°F) W: 0.0 to 2300.0 (°C) / 32 to 4200 (°F) PL2: 0.0 to 1390.0 (°C) / 32.0 to 2500.0 (°F) P2040: 0.0 to 1900.0 (°C) / 32 to 3400 (°F) WRE: 0.0 to 2000.0 (°C) / 32 to 3600 (°F) JPT1: -200.0 to 500.0 (°C) / -300.0 to 1000.0 (°F) JPT2: -150.0 to 150.0 (°C) / -200.0 to 300.0 (°F) PT1: -200.0 to 850.0 (°C) / -300.0 to 1560.0 (°F) PT2: -200.0 to 500.0 (°C) / -300.0 to 1000.0 (°F) PT3: -150.0 to 150.0 (°C) / -200.0 to 300.0 (°F) 0.4-2V: 0.400 to 2.000 V 1-5V: 1.000 to 5.000 V 4-20: 4.00 to 20.00 mA 0-2V: 0.000 to 2.000 V 0-10V: 0.00 to 10.00 V 0-20: 0.00 to 20.00 mA -1020: -10.00 to 20.00 mV 0-100: 0.0 to 100.0 mV Note: W: W-5% Re/W-26% Re (Hoskins Mfg. Co.), ASTM E988 WRE: W97Re3-W75Re25	OFF	
	UNIT	PV input unit	EASY	-: No unit C: Degree Celsius -: No unit --: No unit ---: No unit F: Degree Fahrenheit	C	
	RH	Maximum value of PV input range	EASY	Depends on the input type. - For temperature input - Set the temperature range that is actually controlled. (RL<RH)	Depends on the input type	
	RL	Minimum value of PV input range	EASY	- For voltage / current input - Set the range of a voltage / current signal that is applied. The scale across which the voltage / current signal is actually controlled should be set using the maximum value of input scale (SH) and minimum value of input scale (SL). (Input is always 0% when RL = RH.)	Depends on the input type	
	SDP	PV input scale decimal point position	EASY	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places	Depends on the input type	
	SH	Maximum value of PV input scale	EASY	-19999 to 30000, (SL<SH), SH - SL ≤ 30000	Depends on the input type	
	SL	Minimum value of PV input scale	EASY	-19999 to 30000, (SL<SH), SH - SL ≤ 30000	Depends on the input type	
	BSL	PV input burnout action	STD	OFF: Disable UP: Upscale DOWN: Downtscale	Depends on the input type	
	RJC	PV input reference junction compensation	PRO	OFF: RJC OFF ON: RJC ON	ON	
	ERJC	PV input external RJC setpoint	PRO	-10.0 to 60.0 (°C)	0.0	
	A.BS	PV analog input bias	STD	-100.0 to 100.0% of PV input range span (EUS)	0.0 % of PV input range span	
	A.FL	PV analog input filter	STD	OFF, 1 to 120 s	OFF	

Input Range/SP Limiter Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
MPV	P.UNI	Control PV input unit	STD	-: No unit C: Degree Celsius -: No unit --: No unit ---: No unit F: Degree Fahrenheit	Same as PV input unit	
	P.DP	Control PV input decimal point position	STD	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places 4: Four decimal places	Depends on the input type	
	P.RH	Maximum value of control PV input range	STD	-19999 to 30000, (P.RL<P.RH), P.RH - P.RL ≤ 30000	Depends on the input type	
	P.RL	Minimum value of control PV input range	STD	-19999 to 30000, (P.RL<P.RH), P.RH - P.RL ≤ 30000	Depends on the input type	
	SPH	SP high limit	STD	0.0 to 100.0% of PV input range (EU), (SPL<SPH) Place limits on the program setpoints or the local setpoints when the controller is in program operation. * Places the limit on the program setpoint, local setpoint during program operation. * When LP2 lamp is on, SPH and SPL limit the program setpoint for program pattern 2 retransmission.	100.0 % of PV input range	
	SPL	SP low limit	STD	0.0 to 100.0% of PV input range (EU), (SPL<SPH) Place limits on the program setpoints or the local setpoints when the controller is in program operation. * Places the limit on the program setpoint, local setpoint during program operation. * When LP2 lamp is on, SPH and SPL limit the program setpoint for program pattern 2 retransmission.	0.0 % of PV input range	

Output Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
OUT	OT	Output type selection	EASY	Control output or Heating-side control output (Lower two digits) 00: OFF 01: OUT terminals (voltage pulse) 02: OUT terminals (current) 03: OUT terminals (relay/triac) 06: OUT2 terminals (relay) 07: RET/OUT2 terminals (voltage pulse) 08: RET/OUT2 terminals (current) Cooling-side control output (Upper two digits) 00: OFF 01: OUT terminals (voltage pulse) 02: OUT terminals (current) 03: OUT terminals (relay/triac) 06: OUT2 terminals (relay) 07: RET/OUT2 terminals (voltage pulse) 08: RET/OUT2 terminals (current)	Standard type: 00.03 Heating/cooling type: 06.03	
	CT	Control output cycle time Heating-side control output cycle time (in Heating/cooling control)	EASY	0.5 to 1000.0 s	30.0 s	
	CTc	Cooling-side control output cycle time	EASY		30.0 s	
	V.AT	Automatic valve position adjustment	EASY	OFF: Stop automatic adjustment ON: Start automatic adjustment	OFF	
	V.RS	Valve position setting reset	EASY	Setting V.RS to ON resets the valve adjustment settings and causes the indication "V.RS" to blink.	OFF	
	V.L	Fully-closed valve position setting	EASY	Pressing the SET/ENTER key with valve position set to the fullyclosed position by Down arrow key causes the adjusted value to be stored. When V.L adjustment is complete, V.L stops blinking.	-	
	V.H	Fully-open valve position setting	EASY	Pressing the SET/ENTER key with valve position set to the fullyopened position by Up arrow key causes the adjusted value to be stored. When V.H adjustment is complete, V.H stops blinking.	-	
	TR.T	Valve traveling time	STD	5 to 300 s	60 s	
	V.MOD	Valve adjusting mode	STD	0: Valve position feedback type 1: Valve position feedback type (moves to the estimating type if a feedback input error or break occurs.) 2: Valve position estimating type	0	
	RTS	Retransmission output type of RET	EASY	OFF: Disable PV1: PV SP1: SP OUT1: OUT (Valve opening: 0 to 100 % in Position proportional control) LPS: 15 V DC loop power supply TSP1: Target SP HOUT1: Heating-side OUT COUT1: Cooling-side OUT MV1: Position proportional output internal computed value) PV: PV terminals analog input	PV1	
	RTH	Maximum value of retransmission output scale of RET	STD	When RTS = PV1, SP1, TSP1, or PV RTL + 1 digit to 30000 -19999 to RTH - 1 digit Decimal point position: When RTS=PV1, SP1, or TSP1, decimal point position is same as that of PV input. When RTS=PV, decimal point position is same as that of PV input scale.	100 % of PV input range	
	RTL	Minimum value of retransmission output scale of RET	STD		0 % of PV input range	
	O1RS	Retransmission output type of OUT current output	STD	Same as RTS	OFF	
	O1RH	Maximum value of retransmission output scale of OUT current output	STD	When O1RS = PV1, SP1, TSP1, or PV O1RL + 1 digit to 30000 -19999 to O1RH - 1 digit Decimal point position: When O1RS=PV1, SP1, or TSP1, decimal point position is same as that of PV input. When O1RS =PV, decimal point position is same as that of PV input scale.	-	
	O1RL	Minimum value of retransmission output scale of OUT current output	STD		-	
	OU.A	OUT current output range	STD	4-20: 4 to 20 mA 0-20: 0 to 20 mA 20-4: 20 to 4 mA 20-0: 20 to 0 mA	4-20	
	RET.A	RET current output range	STD		4-20	

Heater Break Alarm Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
HBA	HB1.S	Heater break alarm-1 function selection	EASY	0: Heater current measurement 1: Heater break alarm (Heatingside) 2: Cooling-side heater break alarm	1	
	HB2.S	Heater break alarm-2 function selection	EASY		1	
	HB1	Heater break alarm-1 current setpoint	EASY	OFF, 0.1 to 300.0 Arms	OFF	
	HB2	Heater break alarm-2 current setpoint	EASY		OFF	
	CT1.T	CT1 coil winding number ratio	EASY	1 to 3300	800	
	CT2.T	CT2 coil winding number ratio	EASY		800	
	HDN1	Heater break alarm-1 Ondelay timer	STD		0.00	
	HDN2	Heater break alarm-2 Ondelay timer	STD	0.00 to 99.59 (minute.second)	0.00	
	HDF1	Heater break alarm-1 Offdelay timer	PRO		0.00	
	HDF2	Heater break alarm-2 Offdelay timer	PRO		0.00	
	HB1.D	Heater break alarm-1 contact type	PRO	CLS: When the event occurs, the contact is closed.	CLS	
	HB2.D	Heater break alarm-2 contact type	PRO	OPN: When the event occurs, the contact is opened.	CLS	

RS-485 Communication Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
R485	PSL	Protocol selection	EASY	PCL: PC link communication PLCM: PL link communication (with checksum) LADR: Ladder communication CO-M: Coordinated master station MBASC: Modbus (ASCII) MBRTU: Modbus (RTU) P-P: Peer-to-peer communication	MBRTU	
	BPS	Baud rate	EASY	600: 600 bps 1200: 1200 bps 2400: 2400 bps 4800: 4800 bps 9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	19200	
	PRI	Parity	EASY	NONE: None EVEN: Even ODD: Odd	EVEN	
	STP	Stop bit	EASY	1: 1 bit, 2: 2 bits	1	
	DLN	Data length	EASY	7: 7 bits, 8: 8 bits	8	
	ADR	Address	EASY	1 to 99	1	
	RP.T	Minimum response time	PRO	0 to 10 (x10ms)	0	

When each parameter is displayed, the terminal area (E3) is displayed on Group display.

Ethernet Communication Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
ETHR	HSR	High-speed response mode	EASY	OFF, 1 to 8	1	
	BPS	Baud rate	EASY	9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	38400	
	PRI	Parity	EASY	NONE: None EVEN: Even ODD: Odd	EVEN	
	IP1	IP address 1	EASY	0 to 255	192	
	IP2	IP address 2	EASY	0 to 255	168	
	IP3	IP address 3	EASY	0 to 255	1	
	IP4	IP address 4	EASY	0 to 255	1	
	SM1	Subnet mask 1	EASY	0 to 255	255	
	SM2	Subnet mask 2	EASY	0 to 255	255	
	SM3	Subnet mask 3	EASY	0 to 255	255	
	SM4	Subnet mask 4	EASY	0 to 255	0	
	DG1	Default gateway 1	EASY	0 to 255	0	
	DG2	Default gateway 2	EASY	0 to 255	0	
	DG3	Default gateway 3	EASY	0 to 255	0	
	DG4	Default gateway 4	EASY	0 to 255	0	
	PRT	Port number	EASY	502, 1024 to 65535	502	
	I PAR	IP access restriction	EASY	OFF: Disable, ON: Enable	OFF	
	1.IP1	Permitted IP address 1-1	EASY	0 to 255	255	
	1.IP2	Permitted IP address 1-2	EASY	0 to 255	255	
	1.IP3	Permitted IP address 1-3	EASY	0 to 255	255	
	1.IP4	Permitted IP address 1-4	EASY	0 to 255	255	
	2.IP1	Permitted IP address 2-1	EASY	0 to 255	255	
	2.IP2	Permitted IP address 2-2	EASY	0 to 255	255	
	2.IP3	Permitted IP address 2-3	EASY	0 to 255	255	
	2.IP4	Permitted IP address 2-4	EASY	0 to 255	255	
	ESW	Ethernet setting switch	EASY	OFF, ON Setting this parameter to "ON" enables the Ethernet communication parameter settings. * The parameter ESW automatically returns to "OFF" after "ON" is set.	OFF	

When each parameter is displayed, the terminal area (E3) is displayed on Group display.

PROFIBUS-DP Communication Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
PROF	BR	Baud rate	EASY	9.6K: 9.6k bps 19.2K: 19.2k bps 93.75K: 93.75k bps 187.5K: 187.5k bps 0.5M: 0.5M bps 1.5M: 1.5M bps 3M: 3M bps 6M: 6M bps 12M: 12M bps AUTO 45.45K: 45.45k bps	AUTO	
				0 to 125	3	
				9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	38400	
				0, 11 to 13	0	
				OFF 1M: 1 minute 10M: 10 minutes 30M: 30 minutes 60M: 60 minutes	OFF	

When each parameter is displayed, the terminal area (E3) is displayed on Group display.

DeviceNet Communication Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
DNET	BR	Baud rate	EASY	125K: 125k bps 250K: 250k bps 500K: 500k bps	125K	
				0 to 63	63	
				9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	38400	
				0, 11 to 13	0	
				OFF 1M: 1 minute 10M: 10 minutes 30M: 30 minutes 60M: 60 minutes	OFF	

When each parameter is displayed, the terminal area (E3) is displayed on Group display.

CC-Link Communication Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
CC-L	BR	Baud rate	EASY	156K: 156k bps 625K: 625k bps 2.5M: 2.5M bps 5M: 5M bps 10M: 10M bps	10M	
				1 to 64	1	
				9600: 9600 bps 19200: 19.2k bps 38400: 38.4k bps	38400	
				0, 11 to 13 (0, 11: Ver.1.10) (12, 13: Ver.2.00)	0	
				OFF 1M: 1 minute 10M: 10 minutes 30M: 30 minutes 60M: 60 minutes	OFF	

When each parameter is displayed, the terminal area (E3) is displayed on Group display.

Key Action Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting	
KEY	RUN	RUN key action setting	RPO	OFF: Disable PROG: Switch to PROG (Start of program operation) RESET: Switch to RESET (Stop of program operation) LOCAL: Switch to LOCAL(LSP) (Start of local-mode operation) P/R: PROG/RESET Switch P/H: PROG/HOLD Switch P/L: PROG/LOCAL(LSP) Switch HLD: Switch to HOLD (Start of hold-mode operation) ADV: Advance of segment A/M: AUTO/MAN switch PRG1: Switch to PROG1 (Start of program-1 operation) PRG2: Switch to PROG2 (Start of program-2 operation) AT: Auto-tuning LTUP: LCD brightness UP LTDN: LCD brightness DOWN BRI: Adjust LCD brightness LCD: LCD backlight ON/OFF switch LAT: Latch release PID: PID tuning switch PTN: Program pattern number switch MODE: Operation mode	PROG		
	RST	RST key action setting	PRO		RESET		
	PTN	PTN key action setting	PRO		PTN		
	MODE	MODE key action setting	PRO		MODE		

Display Function Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
DISP	PCMD	Active color PV display switch	EASY	0: Fixed in white 1: Fixed in red 2: Link to alarm 1 (Alarm OFF: white, Alarm ON: red) 3: Link to alarm 1 (Alarm OFF: red, Alarm ON: white) 4: Link to alarm 1 or 2 (Alarm OFF: white, Alarm ON: red) 5: Link to alarm 1 or 2 (Alarm OFF: red, Alarm ON: white) 6: PV limit (Within range: white, Out of range: red) 7: PV limit (Within range: red, Out of range: white) 8: SP deviation (Within deviation: white, Out of deviation: red) 9: SP deviation (Within deviation: red, Out of deviation: white) 10: Link to DI (ON: red, OFF: white)	0	
PCH		PV color change high limit	EASY	Set a display value when in PV limit or SP deviation. -19999 to 30000 (Set a value within the input range.)	0	
PCL		PV color change low limit	EASY	Decimal point position depends on the input type.	0	
PTSL		Program display pattern selection	STD	PTN: Pattern display SK.RP: Ramp and soak display	PTN	
BAR1		Bar-graph display registration	STD	0: Disable 1: OUT, Heating-side OUT, Internal value in Position proportional control 2: Cooling-side OUT 3: PV 4: SP 5: Deviation 6 to 16: Disable 17: Feedback input (valve opening) 18: PV terminals analog input 22: Disable 23: Time event and alarm status	23	
BDV		Bar-graph deviation display band	STD	0.0 to 100.0% of PV input range span (EUS)	10.0 % of PV input range span	
EV1		EV1 display condition registration	PRO	Setting range: 4001 to 6304 OFF: Disable 4785: Link to PV event-1/local event-1 (Lit when the event occurs) 4786: Link to PV event-2/local event-2 (Lit when the event occurs) 4817: Link to time event-1 (Lit when the event occurs) 4818: Link to time event-2 (Lit when the event occurs) 4819: Link to time event-3 (Lit when the event occurs) 4821: Link to time event-4 (Lit when the event occurs) 4321: Link to alarm-1 (Lit when the alarm occurs) 4322: Link to alarm-2 (Lit when the alarm occurs) 4529: Heater break alarm 1 (Lit when the alarm occurs) 4530: Heater break alarm 2 (Lit when the alarm occurs) 5025 to 5027: Link to DI1-DI3 (Lit when the contact is closed) 5041 to 5045: Link to DI11-DI15 (E1-terminal area) (Lit when the contact is closed) 5089 to 5094: Link to DI41-DI45 (E4-terminal area) (Lit when the contact is closed) 5153 to 5155: Link to AL1-AL3 (Lit when the contact is closed) 5169 to 5173: Link to DO11-DO15 (E1-terminal area) (Lit when the contact is closed) 5217 to 5221: Link to DO41-DO45 (E4-terminal area) (Lit when the contact is closed) * For other functions, see the UTAdvanced Series Communication Interface User's Manual.	4785	
EV2		EV2 display condition registration	PRO	5025 to 5027: Link to DI1-DI3 (Lit when the contact is closed) 5041 to 5045: Link to DI11-DI15 (E1-terminal area) (Lit when the contact is closed) 5089 to 5094: Link to DI41-DI45 (E4-terminal area) (Lit when the contact is closed) 5153 to 5155: Link to AL1-AL3 (Lit when the contact is closed) 5169 to 5173: Link to DO11-DO15 (E1-terminal area) (Lit when the contact is closed) 5217 to 5221: Link to DO41-DO45 (E4-terminal area) (Lit when the contact is closed) * For other functions, see the UTAdvanced Series Communication Interface User's Manual.	4786	
PV.D		PV display area ON/OFF	PRO	ON		
SP.D		Setpoint display area ON/OFF	PRO	OFF: Nondisplay, ON: Display	ON	
STS.D		Status display area ON/OFF	PRO	ON		
SPD		Scroll speed	PRO	(Slow) 1 to 8 (Quick)	4	
GUID		Guide display ON/OFF	STD	OFF: Nondisplay ON: Display	ON	
HOME		Home Operation Display setting	PRO	SP1: SP Display OUT1: OUT Display HCO: Heating/cooling OUT Display VP: Valve Position Display MV: Position Proportional Computation Output Display PID1: PID Number Display HC1: Heater Break Alarm-1 Current Display HC2: Heater Break Alarm-2 Current Display PV: PV Analog Input Display CS1 to CS5: SELECT Display 1 to 5 TSP: TSP Display R.TIM: Remaining Segment-tim Display SEG.N: Segment Number Dispaly R.CYC: Remaining Repetition Display PTN: Program Pattern Display	SP1	
ECO		Economy mode	STD	OFF: Disable 1: Economy mode ON (All indications except PV display OFF) 2: Economy mode ON (All indications OFF) 3: Brightness 10 % (All indications)	OFF	
BRI		Brightness	EASY	(Dark) 1 to 5 (Bright)	3	
B.PVW		White brightness adjustment of PV display	PRO	Adjusts the white brightness of PV display. (Dark) -4 to 4 (Bright)	0	
B.PVR		Red brightness adjustment of PV display	PRO	Adjusts the red brightness of PV display. (Dark) -4 to 4 (Bright)	0	
B.SP		Brightness adjustment of Setpoint display	PRO	Adjusts the brightness of SP display. (Dark) -4 to 4 (Bright)	0	
B.BAR		Brightness adjustment of Bargraph display	PRO	Adjusts the brightness of Bargraph display. (Dark) -4 to 4 (Bright)	0	
B.STS		Brightness adjustment of Status indicator	PRO	Adjusts the brightness of Status indicator. (Dark) -4 to 4 (Bright)	0	
D.CYC		Display update cycle	PRO	1: 100 ms 2: 200 ms 3: 500 ms 4: 1 s 5: 2 s	2	
OP.JP		Autoreturn to operation display	PRO	Automatically returned to the Operation Display when there has been no keystroke operation for 5 minutes. OFF, ON	ON	
MLSD		Least significant digital mask of PV display	STD	OFF: With least significant digit ON: Without least significant digit	OFF	

SELECT Display Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
CSEL	CS1	SELECT Display-1 registration	STD		OFF	
	CS2	SELECT Display-2 registration	STD		OFF	
	CS3	SELECT Display-3 registration	STD		OFF	
	CS4	SELECT Display-4 registration	STD		OFF	
	CS5	SELECT Display-5 registration	STD		OFF	
	CS10	SELECT parameter-10 registration	PRO	OFF, 2201 to 5000 For the D register number, see the UTAdvanced Series Communication Interface User's Manual	OFF	
	CS11	SELECT parameter-11 registration	PRO	Main registration parameters - Group 1 (S.PID=1) Control output high limit (OH): 3004, Control output low limit (OL): 3005, Cooling-side control output high limit (OHC): 3016, Cooling-side control output low limit (OLC): 3017	OFF	
	CS12	SELECT parameter-12 registration	PRO	- Group 2 (S.PID=2) Control output high limit (OH): 3054, Control output low limit (OL): 3055, Cooling-side control output high limit (OHC): 3066, Cooling-side control output low limit (OLC): 3067	OFF	
	CS13	SELECT parameter-13 registration	PRO	- Group 3 (S.PID=3) Control output high limit (OH): 3104, Control output low limit (OL): 3105, Cooling-side control output high limit (OHC): 3116, Cooling-side control output low limit (OLC): 3117	OFF	
	CS14	SELECT parameter-14 registration	PRO	- Group 4 (S.PID=4) Control output high limit (OH): 3154, Control output low limit (OL): 3155, Cooling-side control output high limit (OHC): 3166, Cooling-side control output low limit (OLC): 3167	OFF	
	CS15	SELECT parameter-15 registration	PRO	Alarm-1 setpoint (A1): 2351, Alarm-2 setpoint (A2): 2352	OFF	
	CS16	SELECT parameter-16 registration	PRO		OFF	
	CS17	SELECT parameter-17 registration	PRO		OFF	
	CS18	SELECT parameter-18 registration	PRO		OFF	
	CS19	SELECT parameter-19 registration	PRO		OFF	

Key Lock Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
KLOC	U.SP	SP Display lock	PRO		OFF	
	U.TSP	TSP Display lock	PRO		OFF	
	U.TM	Remaining Segment-tim Display lock	PRO		OFF	
	U.OUT	OUT Display lock	PRO		OFF	
	U.HCO	Heating/cooling OUT Display lock	PRO		OFF	
	U.VP	Valve Position Display lock	PRO		OFF	
	U.MV	Position Proportional Computation Output Display lock	PRO	OFF: Display ON: Nondisplay	ON	
	U.PID	PID Number Display lock	PRO		ON	
	U.SEG	Segment Number Display lock	PRO		OFF	
	U.RCY	Remaining Repetition Display lock	PRO		OFF	
	U.PTN	Program Pattern Display lock	PRO		OFF	
	U.HC	Heater Break Alarm Current Value Display lock	PRO		OFF	
	U.PV	PV Analog Input Display lock	PRO		ON	
	COM.W	Communication write enable/disable	STD	OFF: Enable, ON: Disable	OFF	
	DATA	Front panel parameter data key lock	STD		OFF	
	RUN	Front panel RUN key lock	STD		OFF	
	RST	Front panel RST key lock	STD	OFF: Unlock ON: Lock	OFF	
	PTN	Front panel PTN key lock	STD		OFF	
	MODE	Front panel MODE key lock	STD		OFF	

Menu Lock Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
MLOC	CTL	[CTL] menu lock	PRO	OFF: Display ON: Nondisplay	OFF	
	PV	[PV] menu lock	PRO		OFF	
	MPV	[MPV] menu lock	PRO		OFF	
	OUT	[OUT] menu lock	PRO		OFF	
	HBA	[HBA] menu lock	PRO		OFF	
	R485	[R485] menu lock	PRO		OFF	
	ETHR	[ETHR] menu lock	PRO		OFF	
	PROF	[PROF] menu lock	PRO		OFF	
	DNET	[DNET] menu lock	PRO		OFF	
	CC-L	[CC-L] menu lock	PRO		OFF	
	KEY	[KEY] menu lock	PRO		OFF	
	DISP	[DISP] menu lock	PRO		OFF	
	CSEL	[CSEL] menu lock	PRO		OFF	
	KLOC	[KLOC] menu lock	PRO		OFF	
	DI.SL	[DI.SL] menu lock	PRO		OFF	
	DI.NU	[DI.NU] menu lock	PRO		OFF	
	DI.D	[DI.D] menu lock	PRO		OFF	
	ALM	[ALM] menu lock	PRO		OFF	
	DO	[DO] menu lock	PRO		OFF	
	I/O	[I/O] menu lock	PRO		OFF	
	SYS	[SYS] menu lock	PRO		OFF	
	INIT	[INIT] menu lock	PRO		OFF	
	VER	[VER] menu lock	PRO		OFF	
	LVL	[LVL] menu lock	PRO		OFF	
	MODE	[MODE] menu lock	PRO		OFF	
	CS	[CS] menu lock	PRO		OFF	
	PROG	[PROG] menu lock	PRO		OFF	
	LOC	[LOC] menu lock	PRO		OFF	
	EDIT	[EDIT] menu lock	PRO		OFF	
	AL	[AL] menu lock	PRO		OFF	
	SPS	[SPS] menu lock	PRO		OFF	
	ALRM	[ALRM] menu lock	PRO		OFF	
	PVS	[PVS] menu lock	PRO		OFF	
	PID	[PID] menu lock	PRO		OFF	
	TUNE	[TUNE] menu lock	PRO		OFF	
	ZONE	[ZONE] menu lock	PRO		OFF	
	PPAR	[PPAR] menu lock	PRO		OFF	

When each parameter is displayed, the terminal area (E1 to E4) is displayed on Group display.

• Parameter: R485, ETHR, PROF, DNET, CC-L, DI.D, DO, AL, SPS, ALRM, PVS, PID, TUNE, ZONE

DI Function Registration

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
DI.SL	PRG	Switch to PROG (Start of program operation)	STD	Set an I relay number of contact input. Set "OFF" to disable the function.	5025	
	RST	Switch to RESET (Stop of program operation)	STD		5026	
	LOC	Switch to LOCAL(LSP) (Start of local-mode operation)	STD		5027	
	P/R	PROG/RESET Switch	STD		OFF	
	P/H	PROG/HOLD Switch	STD		OFF	
	P/L	PROG/LOCAL(LSP) Switch	STD		OFF	
	HOLD	Switch to HOLD (Start of hold-mode operation)	STD		OFF	
	ADV	Advance of segment	STD		OFF	
	WAIT	Wait ON/OFF switch	STD		OFF	
	S.HLD	Switch to HOLD for synchronized program operation	PRO		OFF	
	A/M	AUTO/MAN switch	STD		OFF	
	AT	Auto-tuning START/STOP switch	STD		OFF	
	LAT	Latch release	STD		OFF	
	LCD	LCD backlight ON/OFF switch	STD		OFF	
	PVRW	PV red/white switch	STD		OFF	
	MG1	Message display interruption 1	PRO		OFF	
	MG2	Message display interruption 2	PRO		OFF	
	MG3	Message display interruption 3	PRO		OFF	
	MG4	Message display interruption 4	PRO		OFF	

DI Function Numbering

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
DI.NU	PT.B0	Bit-0 of Program pattern number	EASY	Set an I relay number of contact input. Set "OFF" to disable the function.	5089	
	PT.B1	Bit-1 of Program pattern number	EASY		5090	
	PT.B2	Bit-2 of Program pattern number	EASY		5091	
	PN.B0	Bit-0 of PID number	STD		OFF	
	PN.B1	Bit-1 of PID number	STD		OFF	
	PN.B2	Bit-2 of PID number	STD		OFF	
	MP.B0	Bit-0 of manual preset output number	STD		OFF	
	MP.B1	Bit-1 of manual preset output number	STD		OFF	
	MP.B2	Bit-2 of manual preset output number	STD		OFF	
	PT.BC	Bit changing method of program pattern number	PRO		0	
	PN.BC	Bit changing method of PID number	PRO		0	
	MP.BC	Bit changing method of manual preset output number	PRO		0	

DI1-DI3 Contact Type Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
DI.D	DI1.D	DI1 contact type	PRO	0: The assigned function is enabled when the contact input is closed. 1: The assigned function is enabled when the contact input is opened.	0	
	DI2.D	DI2 contact type	PRO		0	
	DI3.D	DI3 contact type	PRO		0	

n: Terminal area number (1 to 4)

DI1-DI3 Contact Type Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting	(E1 terminal area) (DI11-DI15)	(E4 terminal area) (DI41-DI45)
DI.D	DI1.D	DI1 contact type	PRO	0: The assigned function is enabled when the contact input is closed. 1: The assigned function is enabled when the contact input is opened.	0			
	DI2.D	DI2 contact type	PRO		0			
	DI3.D	DI3 contact type	PRO		0			
	DI4.D	DI4 contact type	PRO		0			
	DI5.D	DI5 contact type	PRO		0			

n: Terminal area number (1 to 4)

AL1-AL3 Function Registration

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
ALM	AL1.S	AL1 function selection	STD	Set an I relay number. Setting range: 4001 to 6304 No function: OFF PV event 1: 4801, PV event 2: 4802, Time event 1: 4817, Time event 2: 4818, Time event 3: 4819, Time event 4: 4821, Alarm 1: 4353, Alarm 2: 4354, AUTO (ON) / MAN (OFF) status: 4177, Program RESET status: 4181, Program RUN status: 4182, Local operation status: 4183, HOLD mode status: 4189, Program advance status: 4187, Pattern end signal (1 second): 4265, Pattern end signal (3 seconds): 4266, Pattern end signal (5 seconds): 4267, Wait end signal (1 second): 4257, Wait end signal (3 seconds): 4258, Wait end signal (5 seconds): 4259, FAIL (Normally ON) output: 4256	4801	
	AL2.S	AL2 function selection	STD		4802	
	AL3.S	AL3 function selection	STD		4817	
	OR.S	OUT relay function selection	STD		OFF	
	OR2.S	OUT2 relay function selection	STD		OFF	
	AL1.D	AL1 contact type	PRO		0	
	AL2.D	AL2 contact type	PRO		0	
	AL3.D	AL3 contact type	PRO		0	
	OR.D	OUT relay contact type	PRO		0	
	OR2.D	OUT2 relay contact type	PRO		0	
	DI1.D	DI1 contact type	PRO		0	
	DI2.D	DI2 contact type	PRO		0	

n: Terminal area number (1 to 4)

Menu	Symbol	Name	Display level	Setting range	Initial

I/O Display

Menu	Symbol	Name	Display level	Setting range
I/O	KEY	Key status	PRO	Read only See User's Manual.
	X000	DI1-DI3 status (equipped as standard)	PRO	
	X100	DI11-DI15 status (E1-terminal area)	PRO	
	X400	DI41-DI45 status (E4-terminal area)	PRO	
	Y000	AL1-AL3 status (equipped as standard)	PRO	
	Y100	DO11-DO15 status (E1-terminal area)	PRO	
	Y400	DO41-DO45 status (E4-terminal area)	PRO	

System Setting

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
SYS	R.MD	Restart mode	STD	CONT: Continue action set before power failure. MAN: Start from MAN. RESET: Start from AUTO and RESET. The preset output value is outputted. * Set how the controller should recover from a power failure of 5 seconds or more.	CONT	
	R.TM	Restart timer	STD	0 to 10 s * Set time between power on and the instant where controller starts computation.	0	
	EPO	Input error preset output	STD	0: Preset output 1: 0% output 2: 100% output * Set preset output value when the input burnout or ADC error occurs. Manual output is prioritized when the input burnout occurs in MAN.	0	
	C.GRN	Response as GREEN Series	PRO	OFF: Works as UP35A in communication of device information response or broadcasting. ON: Works as GREEN Series in communication of device information response or broadcasting.	OFF	
	FREQ	Power frequency	EASY	AUTO, 60: 60 Hz, 50: 50 Hz	AUTO	
	QSM	Quick setting mode	EASY	OFF: Disable ON: Enable	ON	
	LANG	Guide display language	EASY	ENG: English FRA: French GER: German SPA: Spanish	Depends on the Model and Suffix Codes	
	PASS	Password setting	EASY	0 (No password) to 65535 Once a password is set, you can no longer choose not to set a password.	0	
	SMEC	Sampling period error counter	PRO	0 to 65535 (display only)	0 when power is turned on.	

Initialization

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
INIT	U.DEF	Initialization to user default value	PRO	12345: Initialization, automatically returned to "0" after initialization.	0	
	F.DEF	Initialization to factory default value	PRO	-12345: Initialization, automatically returned to "0" after initialization.	0	
	P.DEF	Clearing all program pattern data	PRO	13579: Initialization, automatically returned to "0" after initialization. * Data all deletions in menu [PROG]	0	

When the following parameters are displayed, the terminal area (E1 to E4) is displayed on Group display.
 • Parameter: ECU1, ECU4, MAC1, MAC2 and MAC3

Parameter Display Level

Menu	Symbol	Name	Display level	Setting range	Initial value	User setting
LVL	LEVL	Parameter display level	EASY	EASY: Easy setting mode STD: Standard setting mode PRO: Professional setting mode	STD	

UTAdvanced UP35A

Program Pattern Setup Charts

CAUTION Note that the program patterns are all deleted if the settings change after creating program patterns.
Be sure to check the PV input range, Program time unit (TMU), and Segment setting method (SEG.T) before creating.

You can register max. 20 program segments/pattern with the UP35A controller. Create as many copies of the chart as necessary.

You can register max. 20 program segments/pattern with the UP35A controller. Create as many copies of the chart as necessary.

System name	
Program No.	
Program name	
Model	
Serial No.	

The following parameters are necessary to be set before programming.
Note that the program is deleted if TMU or SEG.T is changed after creating programs.

Parameter symbol	Parameter name	User settings
TMU	Program time unit	
SEG.T	Segment setting method	
ZON	Zone PID selection	

The following parameters are common parameters for the program pattern specified.

Parameter symbol	Parameter name	User settings
SSP	Starting target setpoint	
STC	Start code	
WT.SW1	Wait function ON/OFF	
WZ.UP1	Upper-side wait zone	
WZ.LO1	Lower-side wait zone	
WT.TM1	Wait time	
R.CYCL	Number of repeat cycles	
R.START	Repeat cycle start segment number	
R.END	Repeat cycle end segment number	

Maximum value of PV input range / Maximum value of PV input scale (Unit (

A program pattern can be drawn in the right table.

Minimum value of PV input range / Minimum value of PV input scale ()

Category	Sub-Category	Item	Description
Electronics	Smartphones	iPhone 12 Pro	High-end smartphone with 5G support and advanced camera system.
Electronics	Smartphones	Samsung Galaxy S21	Competitor to iPhone 12 Pro, featuring a powerful processor and a sleek design.
Electronics	Laptops	Dell XPS 15	High-performance laptop with a large screen and excellent battery life.
Electronics	Laptops	HP Spectre x360	Thin and light laptop with a convertible screen and a long battery life.
Electronics	Tablets	Apple iPad Pro	Powerful tablet with a high-resolution screen and a range of productivity apps.
Electronics	Tablets	Microsoft Surface Pro 7	Tablet with a built-in keyboard and a range of productivity tools.
Home & Garden	Kitchen Appliances	Kenmore Elite 5-in-1 Smart Robot Vacuum	Robotic vacuum cleaner with a range of cleaning modes and a mobile app interface.
Home & Garden	Kitchen Appliances	JBL Flip 5 Portable Speaker	Portable speaker with a built-in microphone and a range of sound options.
Home & Garden	Decor	West Elm Mid-Century Side Table	Stylish side table with a solid wood frame and a minimalist design.
Home & Garden	Decor	Urban Outfitters Velvet Throw Pillow	Velvet throw pillow with a textured, velvety finish.
Home & Garden	Textiles	Brooklinen Organic Cotton Sheet Set	Organic cotton sheet set with a soft, breathable feel.
Home & Garden	Textiles	Leesa Mattress	Memory foam mattress with a cooling gel-infused cover.
Health & Beauty	Cosmetics	Urban Decay Naked Heat Eyeshadow Palette	Eye shadow palette with a range of warm-toned shades.
Health & Beauty	Cosmetics	Too Faced Better Than Sex Lipstick	Matte lipstick with a bold, vibrant color.
Health & Beauty	Haircare	Redken Volume High Rise Conditioner	Conditioner designed to add volume and texture to fine hair.
Health & Beauty	Haircare	John Frieda Sheer Luxe Conditioner	Conditioner designed to add shine and softness to dry hair.
Health & Beauty	Nails	Essie Gel Couture Nail Polish	Gel-like nail polish with a range of on-trend colors.
Health & Beauty	Nails	China Glaze Nail Polish	Long-lasting nail polish with a range of classic and modern colors.
Books & Media	Books	The Great Gatsby by F. Scott Fitzgerald	Classic novel about the American Dream in the 1920s.
Books & Media	Books	1984 by George Orwell	Iconic dystopian novel about government surveillance and control.
Books & Media	Movies	The Godfather	Classic gangster movie directed by Francis Ford Coppola.
Books & Media	Movies	Star Wars: Episode IV - A New Hope	Iconic science fiction movie directed by George Lucas.
Books & Media	Music	Billie Eilish - When We All Fall Asleep, Where Do We Go?	Debut album by Billie Eilish, featuring hit songs like "Bad Guy".
Books & Media	Music	Drake - Scorpion	Album by Drake featuring guest appearances from various artists.

UTAdvanced UP35A

Program Pattern Setup Charts

CAUTION Note that the program patterns are all deleted if the settings change after creating program patterns.

Be sure to check the PV input range, Program time unit (TMU), and Segment setting method (SEG.T) before creating.

You can register max. 20 program segments/pattern with the UP35A controller. Create as many copies of the chart as necessary.

System name	*****
Program No.	*****
Program name	*****
Model	UP35A
Serial No.	

The following parameters are necessary to be set before programming.
Note that the program is deleted if TMU or SEG.T is changed after creating programs.

Parameter symbol	Parameter name	User settings
TMU	Program time unit	HH.MM
SEG.T	Segment setting method	TIME
ZON	Zone PID selection	0

The following parameters are common parameters for the program pattern specified.

Parameter symbol	Parameter name	User settings
SSP	Starting target setpoint	50.0
STC	Start code	SSP
WT.SW1	Wait function ON/OFF	
WZ.UP1	Upper-side wait zone	
WZ.LO1	Lower-side wait zone	
WT.TM1	Wait time	
R.CYCL	Number of repeat cycles	
R.START	Repeat cycle start segment number	
R.END	Repeat cycle end segment number	

The programming example given here demonstrates how to do the tasks outlined below.

- 1) Program the controller to start program operation at 50.0°C and raise the temperature up to 100.0°C in 50 minutes.
- 2) When the temperature reaches 100.0°C, keep it at this level for 30 minutes.
- 3) Raise the temperature up to 200.0°C in 60 minutes.
- 4) When the temperature reaches 200.0°C, keep it at this level for 30 minutes.
- 5) Lower the temperature to 50.0°C in 50 minutes.
- 6) When the temperature reaches 50.0°C, keep it at this level for 30 minutes.

PV input ranges are following:

Maximum value of PV input range: 250.0°C


Minimum value of PV input range: 0.0°C

PV input unit: C


Zone PID selection (ZON): Segment PID selection (0)

Segment setting method (SEG.T): Segment time setting (TIME)

Program time unit (TMU): hour.minute (HH.MM)



Parameter symbol	Parameter name	Segments																			
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
TSP	Final target setpoint	100.0	100.0	200.0	200.0	50.0	50.0														
TIME	Segment time setting	0.50	0.30	1.00	0.30	0.50	0.30														
TM.RT	Segment ramp-rate setting																				
S.PID	Segment PID number selection	1	2	3	4	3	2														
JC	Junction code	CONT	CONT	CONT	CONT	CONT	CONT														
PV.TY1	PV event-1 type	5	1	5	1	6	2														
PV.EV1	PV event-1 setpoint	5.0	110.0	5.0	210.0	5.0	10.0														
PV.TY2	PV event-2 type																				
PV.EV2	PV event-2 setpoint																				
TME1	Start condition of time event 1	OFF	OFF	ON	OFF	ON	OFF														
T.ON1	On time of time event 1	0.25																			
T.OF1	Off time of time event 1			0.20		0.20															
TME2	Start condition of time event 2	OFF	ON	OFF	ON	OFF	ON														
T.ON2	On time of time event 2																				
T.OF2	Off time of time event 2																				
TME3	Start condition of time event 3																				
T.ON3	On time of time event 3																				
T.OF3	Off time of time event 3																				
TME4	Start condition of time event 4																				
T.ON4	On time of time event 4																				
T.OF4	Off time of time event 4																				



The display symbols of the parameters, TSP (Final target setpoint), TIME (Segment time setting), and S.PID (Segment PID number selection) are the same in each segment. However, the segment can be recognized by the number displayed on the Symbol display.